

WALL MOUNTED MULTI H3M

Service manual

MUPR-H3M



CL20820 to CL20823 English


Table of Contents

Part I:Technical Information	
1. Summary	1
2. Specifications	
2.1 Specification Sheet	
2.2 Noise Criteria Curve Tables for Both Models	
3. Outline Dimension Diagram	5
4. Refrigerant System Diagram	
5. Electrical Part	
5.1 Wiring Diagram	
5.2 PCB Printed Diagram	
6. Function and Control	11
6.1 Remote Controller Introduction	
6.2 Brief Description of Modes and Functions	
Part II: Installation and Maintenance	18
7. Notes for Installation and Maintenanc	:e 18
8. Installation	
8.1 Installation Dimension Diagram	20
8.2 Installation Parts-checking	22
8.3 Selection of Installation Location	
8.4 Requirements Forelectric Connection	
8.6 Check after Installation and Test Operation	
9. Maintenance	26
9.1 Error Code	
9.2 Procedure of Troubleshooting	28
10. Exploded View and Parts' List	34
11. Removal Procedure	
Appendix:	
Appendix 1: Reference Sheet of Celsius and Fahrenheit	
Appendix 2: Configuration of Connection Pipe Appendix 3: Pipe Expanding Method	
Appendix 3: Pipe Expanding Method	
The second secon	

Service manual

Part I: Technical Information

1. Summary



Remote Controller:

YT1F(XFAN) CL98052



2. Specifications

2.1 Specification Sheet


Model		MUPR-07-H3M	MUPR-09-H3M
Product Code		CL20820	CL20821
Rated Voltage	V~	220-240	220-240
Rated Frequency	Hz	50	50
Phases		1	1
Cooling Capacity	KW	2.1	2.6
Heating Capacity	KW	2.6	2.8
Air Flow Volume (SH/H/M/L)	m³/h	450/410/380/320	500/410/380/320
Dehumidifying Volume	L/h	0.6	0.6
Fan Type		Cross-flow	Cross-flow
Fan Diameter-height	mm	Ф85Х596	Ф85X596
Fan Motor Speed (SH/H/M/L) Cool	rpm	1260/1050/920/730	1260/1050/920/730
Fan Motor Speed (SH/H/M/L) Heat	rpm	1320/1200/1100/950	1320/1200/1100/950
Fan Motor Power Output	W	10	10
Fan motor running current	Α	0.144	0.144
Fan Motor Capacitor	μF	1	1
Evaporator Material		Aluminum Fin-copper Tube	Aluminum Fin-copper Tube
Evaporator Pipe Diameter	mm	7	7
Evaporator Number of Rows		2	2
Evaporator Fin Pitch	mm	1.5	1.5
Evaporator Length(L)XHeight(H)XWidth(W)	mm	581X267X25.4	581X267X25.4
Motor Model		FN10A-PG	FN10A-PG
Overload Protector		3.15	3.15
Motor Full Load Amp(FLA)	Α	0.144	0.144
Sound Pressure Level (SH/H/M/L)	dB (A)	36/34/31/28	37/34/31/28
Sound Power Level (SH/H/M/L)	dB (A)	51/49/46/43	52/49/46/43
Outline Dimension (WXHXD)	mm	790X174X265	790X174X265
Package Carton Dimension (LXWXH)	mm	870X248X355	870X248X355
Package Dimension (LXWXH)	mm	873X251X370	873X251X370
Net Weight	kg	9	9
Gross Weight	kg	11	11
Liquid pipe	mm	Ф6	Ф6
Gas Pipe(to indoor unit)	mm	Ф9.52	Ф9.52
Note: The connection pipe applies metric dian	neter.		

The above data is subject to change without notice; please refer to the nameplate of the unit.

Model		MUPR-12-H3M	MUPR-18-H3M
Product Code		CL20822	CL20823
Rated Voltage	V~	220-240	220-240
Rated Frequency	Hz	50	50
Phases		1	1
Cooling Capacity	KW	3.5	5.3
Heating Capacity	KW	3.8	5.8
Air Flow Volume (SH/H/M/L)	m³/h	630/500/420/350	850/780/650/550
Dehumidifying Volume	L/h	1.4	1.8
Fan Type		Cross-flow	Cross-flow
Fan Diameter-height	mm	Ф92Х645	Ф98Х710
Fan Motor Speed (SH/H/M/L) Cool	rpm	1260/1070/880/730	1350/1150/1050/900
Fan Motor Speed (SH/H/M/L) Heat	rpm	1280/1080/1000/920	1420/1250/1150/1050
Fan Motor Power Output	W	20	20
Fan motor running current	Α	0.22	0.31
Fan Motor Capacitor	μF	1	1.5
Evaporator Material		Aluminum Fin-copper Tube	Aluminum Fin-copper Tube
Evaporator Pipe Diameter	mm	7	7
Evaporator Number of Rows		2	2
Evaporator Fin Pitch	mm	1.4	1.4
Evaporator Length(L)XHeight(H)XWidth(W)	mm	690X267X25.4	715X304.8X25.4
Motor Model		FN20J-PG	FN20V-PG
Overload Protector		3.15	3.15
Motor Full Load Amp(FLA)	Α	0.22	0.31
Sound Pressure Level (SH/H/M/L)	dB (A)	38/34/32/30	46/43/40/36
Sound Power Level (SH/H/M/L)	dB (A)	53/49/47/45	61/58/55/51
Outline Dimension (WXHXD)	mm	845X180X275	940X200X298
Package Carton Dimension (LXWXH)	mm	915X255X355	1010X285X380
Package Dimension (LXWXH)	mm	918X258X370	1013X288X395
Net Weight	kg	10	13
Gross Weight	kg	12.5	16
Liquid pipe	mm	Ф6	Ф6
Gas Pipe(to indoor unit)	mm	Ф9.52	Ф12.7
Note: The connection pipe applies metric dian	neter.		


The above data is subject to change without notice; please refer to the nameplate of the unit.

2.2 Noise Criteria Curve Tables for Both Models




Indoor Fan Motor Rotating Speed

3. Outline Dimension Diagram



4. Refrigerant System Diagram



A1:A-unit electronic expansion valve
C1:C-unit electronic expansion valve
D1:D-unit electronic expansion valve
A2:A-unit gas pipe temperature sensor
C2:C-unit gas pipe temperature sensor
D2:D-unit gas pipe temperature sensor
A3:A-unit liquid pipe temperature sensor
C3:C-unit liquid pipe temperature sensor
D3:D-unit liquid pipe temperature sensor
D3:D-unit liquid pipe temperature sensor

5. Electrical Part

5.1 Wiring Diagram


Instruction

Symbol	Symbol Color	Symbol	Symbol Color	Symbol Name	
WH	White	GN	Green	Green CAP Jumper cap	
YE	Yellow	BN	Brown	COMP Compressor	
RD	Red	BU	Blue	-	Grounding wire
YEGN	Yellow/Green	BK	Black	/	1
VT	Violet	OG	Orange	/	1


Note: Jumper cap is used to determine fan speed and the swing angle of horizontal lover for this model.

• Indoor Unit

(1)07/09/12K Units



(2)18K Units




These wiring diagrams are subject to change without notice; please refer to the one supplied with the unit.

5.2 PCB Printed Diagram


(1)07/09/12K Units

• Top view




1	Power supply live wire
'	connector
2	Power supply neutral wire
	connector
3	Fan capacitor
4	Health function terminal
4	(optional)
5	Indoor fan wire terminal
6	Indoor and outdoor unit
0	communication wire terminal
7	Up & down swing control
′	terminal
8	Indoor fan feedback terminal
9	Jumper cap terminal
10	Display panel terminal
11	Indoor ambient temperature
11	sensor
12	Indoor pipe temperature sensor
13	Protective tube

Bottom view




(2)18K Units

• Top view



Interface of neutral wire
Interface of PG motor
Interface of health function live
wire
Interface of auto button
Interface of up and down swing
Interface of PG feedback
Interface of indoor and outdoor
unit communication
Interface of display
Interface of jumper cap
Interface of ambient temperature
sensor
Interface of tube temperature
sensor
Interface of health function
neutral wire
Interface of live wire
Interface of fuse

• Bottom view



6. Function and Control

6.1 Remote Controller Introduction



ON/OFF

Press it to start or stop operation.

2 -:

Press it to decrease temperature setting.

3 +:

Press it to increase temperature setting.

4 FAN

Press it to set fan speed.

5 MODE

Press it to select operation mode (AUTO/COOL/DRY/FAN/HEAT).

6 I FEEL

7 🕏

Press it to set HE ALTH function

8 8

Press it to set AIR function.

9 CLOCK

Press it set clock.

10 TIMER ON

Press it to set auto-on timer.

11


Press it set swing angle.

- 12 X-FAN (X-FAN is the alternative expression of BLOW for the purpose of understanding.)
- 13 TEMP
- 14 TIMER OFF

Press it to set auto-off timer

- 15 TURBO
- 16 SLEEP
- 17 LIGHT

Press it to turn on/off the light.



18 MODE icon:

If MODE button is pressed, current operation mode icon \triangle (AUTO), & (COOL), & (DRY), & (FAN) or \triangle (HEAT only for heat pump models) will show.

19 SLEEP icon:

is displayed by pressing the SLEEP button. Press this button again to clear the display.

20 TEMP icon: (" ☐ι "function is applicable to partial of models.)

Pressing TEMP button, 🖒 (set temperature), 🏚 (ambient temperature), 🗘 (outdoor ambient temperature) and blank is displayed circularly.

21 Up & down swing icon:

刻 is displayed when pressing the up & down swing button. Press this button again to clear the display.

22 LIGHT icon:

is displayed by pressing the LIGHT button. Press LIGHT button again to clear the display.

23 LOCK icon:

is displayed by pressing "+" and "-" buttons simultaneously. Press them again to clear the display.

24 SET TIME display:

After pressing TIMER button, ON or OFF will blink. This area will show the set time.

25 TURBO icon:

⑤ is displayed when pressing the TURBO button. Press this button again to clear the display.

26 DIGITAL display:

This area will show the set temperature. During defrosting operation, "H1" will be displayed.

27 AIR icon: (NOTE: This function is applicable to partial of models.)

🖒 is displayed when pressing the AIR button. Press this button again to clear the display.

28 I FEEL icon:

is displayed when pressing the I FEEL button. Press this button again to clear the display.

29 FAN SPEED display:

Press FAN button to select the desired fan speed setting (AUTO-Low-Med-High). Your selection will be displayed in the LCD windows, except the AUTO fan speed.

30 HEALTH icon:

齐 is displayed when pressing the HEALTH button. Press this button again to clear the display.

31 X-FAN icon:

his displayed when pressing the X-FAN button. Press this button again to clear the display.

Remote Controller Description

ON/OFF:

Press this button to turn on the unit .Press this button again to turn off the unit.

2 -:


Press this button to decrease set temperature. Hold it down for above 2 seconds to rapidly decrease set temperature. In AUTO mode, set temperature is not adjustable.

3 +

Press this button to increase set temperature. Hold it down for above 2 seconds to rapidly increase set temperature. In AUTO mode, set temperature is not adjustable.

4 FAN:

This button is used for setting Fan Speed in the sequence that goes from AUTO, - , - , - to then back to Auto.



5 MODE:

Each time you press this button, a mode is selected in a sequence that goes from AUTO, COOL, DRY, FAN, and HEAT *, as the following:



*Note: Only for models with heating function.

After energization, AUTO mode is defaulted. In AUTO mode, the set temperature will not be displayed on the LCD, and the unit will automatically select the suitable operation mode in accordance with the room temperature to make indoor room comfortable.

6 | FEEL:

Press this button to turn on I FEEL function. The unit automatically adjust temperature according to the sensed temperature. Press this button again to cancel I FEEL function.

7 🕏

Press this button to set HEALTH function ON or OFF. After the unit is turned on, it defaults to HEALTH function ON.

8 1 (NOTE: This function is applicable to partial of models.)

Press this button to select AIR function ON or OFF.

9 CLOCK:

Pressing CLOCK button, blinks. Within 5 seconds, pressing + or - button adjusts the present time. Holding down either button above 2 seconds increases or decreases the time by 1 minute every 0.5 second and then by 10 minutes every 0.5 second. During blinking after setting, press CLOCK button again to confirm the setting, and then will be constantly displayed.

10 TIMER ON:

Press this button to initiate the auto-ON timer. To cancel the auto-timer program, simply press this button again.

After pressing this button, disappears and "ON" blinks . 00:00 is displayed for ON time setting. Within 5 seconds, press + or - button to adjust the time value. Every press of either button changes the time setting by 1 minute. Holding down either button rapidly changes the time setting by 1 minute and then 10 minutes. Within 5 seconds after setting, press TIMER ON button to confirm.

11 🔰

Press this button to set up & down swing angle, which circularly changes as below:

indicates the guide louver swings as:

12 X-FAN:

Pressing X -FAN button in COOL or DRY mode, the icon % is displayed and the indoor fan will continue operation for 2 minutes in order to dry the indoor unit even though you have turned off the unit. After energization, X-FAN OFF is defaulted. X-FAN is not available in AUTO, FAN or HEAT mode.

13 TEMP:

Press this button, you can see indoor set temperature, indoor ambient temperature on indoor unit's display. The setting on remote controller is selected circularly as below:

When selecting " \bigcirc " with remote controller or no display, temperature indicator on indoor unit displays set temperature; When selecting " \bigcirc " with remote controller, temperature indicator on indoor unit displays indoor ambient temperature; 3s later or within 3s it receives other remote control signal that will return to display the setting temperature.

Caution:

- •This model hasn't outdoor ambient temperature display function. While remote controller can operate "☐₃"and indoor unit displays set temperature.
- •It's defaulted to display set temperature when turning on the unit.
- •Only for the models with temperature indicator on indoor unit.

14 TIMER OFF:

Press this button to initiate the auto-off timer. To cancel the auto-timer program, simply press the button again. TIMER OFF setting is the same as TIMER ON.

15 TURBO:

Press this button to activate/deactivate the Turbo function which enables the unit to reach the preset temperature in the shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed. (This function is not applicable for some models).

16 SLEEP:

Press this button to go into the SLEEP operation mode. Press it again to cancel this function. This function is available in COOL, HEAT (Only for models with heating function) mode to maintain the most comfortable temperature for you.

17 LIGHT:

Press LIGHT button to turn on the display's light and press this button again to turn off the display's light. If the light is turned on, $\frac{1}{2}$ is displayed. If the light is turned off, $\frac{1}{2}$ disappears.

18 Combination of "+" and "-" buttons: About lock

Press "+" and "-" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked, \blacksquare is displayed. In this case, pressing any button, \blacksquare blinks three times.

19 Combination of "MODE" and "-" buttons: About switch between Fahrenheit and Centigrade At unit OFF, press "MODE" and "-" buttons simultaneously to switch between °C and °F.


Replacement of Batteries


- 1.Remove the battery cover plate from the rear of the remote controller. (As shown in the figure)
- 2. Take out the old batteries.
- 3.Insert two new AAA1.5V dry batteries, and pay attention to the polarity.
- 4. Reinstall the battery cover plate.

Notes:

- •When replacing the batteries, do not use old or different types of batteries, otherwise, it may cause malfunction.
- •If the remote controller will not be used for a long time, please remove batteries to prevent batteries from leaking.
- •The operation should be performed in its receiving range.
- •It should be kept 1m away from the TV set or stereo sound sets.
- •If the remote controller does not operate normally, please take the

batteries out and reinsert them after 30 seconds. If it still can't operate properly,replace the batteries.





Sketch map for replacing batteries

6.2 Brief Description of Modes and Functions


I. Basic Operation Mode

1. Cool; 2.Dry; 3.Heat; 4.Auto; 5.Fan

II. Basic Functions

1.Cooling Only

(1) Under this mode, fan and swing run at preset status, the temperature setting range is 16-30°C.



(2) Under malfunction for outdoor unit and protection stop, the indoor unit runs with the original status, and display malfunction.


(3) The indoor fan stops when the modes conflict with each other.

2. Dry Mode

- (1) Under this mode, the indoor fan runs with low speed, and swing runs at preset status, the temperature setting range is 16-30°C.
- (2) Under malfunction for outdoor unit and protection stop, the indoor unit runs with the original status, and display malfunction.

3. Heating Mode

(1) Under this mode, the temperature setting range is 16-30°C.



(2) Working condition and Process of Heating

When the unit is ON and in heating mode, indoor fan starts cold air prevention operation; when the unit is off and the indoor fan stopped before, it blows residual heat.


(3) Protection Function. The compressor stops as the malfunction (including any temperature sensor malfunction) in heating mode, the indoor fan runs with blowing residual heat.

(4) Defrosting and Oil Return

Once defrosting signal of outdoor unit is received, Heating indicator on indoor unit OFF 0.5s and ON 10s.

4. Working Methods of Auto Mode

- 1) When Tamb.≥26°C, it operates in Cool mode.
- 2) For heat pump unit, when Tamb.≤22°C, it operates in Heat mode.
- 3) When 22°C< Tamb.< 26°C, it operates in auto fan mode upon initial startup of the unit. When changing to auto mode from other modes, it will keep the previous operation mode (when it enter Dry mode, it operates in auto fan mode.).



With compressor capacity supplied With no compressor capacity supplied

5. Fan Mode

Only indoor fan operates in Fan mode. Under auto fan speed, it runs in cooling auto fan mode.

III. Other Control

1. Buzzer

The buzzer will give out a beep when the controller is energized, receiving signal from remote controller and auto button.

2. Auto Button

Press this button once, it will operate in Auto mode, and indoor fan operates in Auto fan mode and swing. When the unit is on, pressing this button will turn off the unit.

3 Auto Fan

a. Auto fan speed under heating mode

When Tinddor amb. ≤Tpreset+1°C, indoor fan operates at high speed;

When Tpreset+1°C<T inddor amb.<Tpreset+3°C, indoor fan operates at medium speed;

When T inddor amb.≥Tpreset+3°C, indoor fan operates at low speed.

b. Auto fan speed under cooling or fan mode

WhenT amb.≥Tpreset+3°C, indoor fan operates at high speed;

When Tpreset+1<T amb.<Tpreset+3°C, indoor fan operates at medium speed;

WhenT amb.≤Tpreset+1°C, indoor fan operates at low speed.


c. Auto fan speed under drying mode is low speed.

During auto fan speed, there's should be at least 3min and 30s operation time when switching between high speed, medium speed and low speed.


Note: Under auto fan speed, it will shift between high speed and middle speed, middle speed and low speed, high speed and low speed, the operation time must be 3.5min at least.

4. Sleep

- 4.1 The unit will select suitable sleep curve according to set temperature.
- 4.2 Sleep curve in Heat mode



4.3 Sleep curve in Cool mode



5. Timer Function

(1) General Timer:

- 1.1 Time On: if Timer On is set when the system is,the controller will operate in the original setting mode after reaching the timer on time. The timer interval is 0.5h, and the setting range is 0.5-24h.
- 1.2 Timer Off: Timer Off can be set when the unit is on. The unit will be off when timer off time is realced. The timer interval is 0.5h, and the setting range is 0.5-24h.

(2) Clock Timer:

- 2.1 Timer On: If Timer On is set when the system runs, it will continue to run; if Timer On is set when the system is off, the system will start to run in the original setting mode when timer on time is reached.
- 2.2 Timer Off: If timer off is set when the system is off, the system keeps stand-by status; if timer off is set when the system is on, the system stops when reaching timer off time.
- 2.3 Timer Change:Timer On and Timer OFF can be set via remote ON/OFF button. Timer time can be reset and the system will operate according to the latest setting.

When the unit is on and Timer On and Timer Off are both set, the system will operate according to the set state. When the timer off time is reached, the system will stop.

When the system stops, and Timer On and Timer Off are both set, the system will remain stop until timer on time is reached. After that, the unit will operate according to the set mode everyday when the timer on time is reached. When the timer off time is reached, the system will stop. If timer on time is the same as timer off time, the system will stop.

6. Memory Function

Memory contents: mode, up& down swing, light, set temperature, set fan speed, general timer (but clock timer). After power failure, if the unit is reenergized, it will operate according to memory contents. If Timer function is not set in the last remote control, the system will operate according to the last remote control.

If general timer function is set in the last remote control and power failure occurs before timer time is reached, the unit will operate according to the timer function set in the last remote control. Timer time is calculated after the unit is re-energized.

If general timer function is set in the last remote control and power failure occurs after timer time is reached, the system will operate according to the memory content before power failure. Timer operation is not memorized.

7. HEALTH Function

When the unit is on and the indoor fan operates, press HEALTH button to start this function (if there is no HEALTH button, HEALTH operation is defaulted). When indoor fan stops or turning of HEALTH function by remote controller, HEALTH function will be off.

8. I Feel Function

When the controller receives I Feel order, the controller will operate according to the ambient temperature. The remote controller will send ambient temperature to the controller every 10min. If the controller does not receive the ambient temperature sent by remote controller for 11min, the air conditioner will operate according the ambient temperature around it. If I Feel function is not set, the air conditioner will operate according the ambient temperature around it. This function is not memorized upon power r failure.

9. Reserved Fahrenheit Temperature

The nixie tube will display the set temperature in Celsius temperature or Fahrenheit Temperature according to the order. Setting range is 16~30°C. In Auto mode, it will display 25°C during cooling and fan operation, and display 20°C during heating operation. For cooling only unit, it displays 25°C.

The indoor temperature displayed is sent by remote controller, ranging from 0~60°C. If outdoor ambient temperature is received, the display remains the same. If valid control signal is received, it will display set temperature for 5s and then resume displaying ambient temperature.

For units with memory function, set temperature will be displayed after re-energizing the unit.

10. Cold Plasma Function(optional)

Turning on the cold plasma function with remote controller when the fan operates, this function will act.

Turning off the cold plasma function with remote controller or turning off the fan, this function will end.

11. Turbo Function

When Turbo command is received by controller, indoor fan will operate at high speed while outdoor unit will operate at high frequency in cooling or heating mode.

12. Forcible Defrosting Function

When the unit is in Heat mode and set temperature is 16°C, press "+, -, +, -, *, successively for 5s, and the indoor unit will enter forcible defrosting setting and send the signal to the outdoor unit.

When the indoor unit receives forcible defrosting signal from the outdoor unit, it will exit forcible defrosting setting.

13. Refrigerant Recovery Function

Enter refrigerant recovery mode: turn on the unit within 5 min after energization and at 16°C cooling mode. Press remote controller light off button successively for 3 times within 3s and the unit will enter refrigerant recovery mode, displaying Fo. The signal will be sent to the outdoor unit.

Exit refrigerant recovery mode: during refrigerant recovery, if any signal from remote controller is received or refrigerant recovery lasts for 25min, it will exit this mode.

Action of entering refrigerant recovery mode: the indoor fan will operate in Cool mode. The fan speed is high and set temperature is 16°C. The horizontal louver will be at the smallest angle.

Action of exit refrigerant recovery mode: the indoor fan will operate according to the last remote control setting.

14. Mode Conflict

When the mode of started unit is different from that of operating unit, the indoor unit will display mode conflict code "E7". The mode sent to the outdoor unit remains the one received by the remote controller.

Part II: Installation and Maintenance

7. Notes for Installation and Maintenance

Safety Precautions: Important!

Please read the safety precautions carefully before installation and maintenance.

The following contents are very important for installation and maintenance.

Please follow the instructions below.

- •The installation or maintenance must accord with the instructions.
- •Comply with all national electrical codes and local electrical codes.
- Pay attention to the warnings and cautions in this manual.
- All installation and maintenance shall be performed by distributor or qualified person.
- •All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.
- •Be caution during installation and maintenance. Prohibit incorrect operation to prevent electric shock, casualty and other accidents.



Warnings

Electrical Safety Precautions:

- 1. Cut off the power supply of air conditioner before checking and maintenance.
- 2. The air condition must apply specialized circuit and prohibit share the same circuit with other appliances.
- 3. The air conditioner should be installed in suitable location and ensure the power plug is touchable.
- 4. Make sure each wiring terminal is connected firmly during installation and maintenance.
- 5. Have the unit adequately grounded. The grounding wire can't be used for other purposes.
- 6. Must apply protective accessories such as protective boards, cable-cross loop and wire clip.
- 7. The live wire, neutral wire and grounding wire of power supply must be corresponding to the live wire, neutral wire and grounding wire of the air conditioner.
- 8. The power cord and power connection wires can't be pressed by hard objects.
- 9. If power cord or connection wire is broken, it must be replaced by a qualified person.

- 10. If the power cord or connection wire is not long enough, please get the specialized power cord or connection wire from the manufacture or distributor. Prohibit prolong the wire by yourself.
- 11. For the air conditioner without plug, an air switch must be installed in the circuit. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.
- 12. Make sure all wires and pipes are connected properly and the valves are opened before energizing.
- 13. Check if there is electric leakage on the unit body. If yes, please eliminate the electric leakage.
- 14. Replace the fuse with a new one of the same specification if it is burnt down; don't replace it with a cooper wire or conducting wire.
- 15. If the unit is to be installed in a humid place, the circuit breaker must be installed.

Installation Safety Precautions:

- 1. Select the installation location according to the requirement of this manual.(See the requirements in installation part)
- 2. Handle unit transportation with care; the unit should not be carried by only one person if it is more than 20kg.
- 3. When installing the indoor unit and outdoor unit, a sufficient fixing bolt must be installed; make sure the installation support is firm.
- 4. Ware safety belt if the height of working is above 2m.
- 5. Use equipped components or appointed components during installation.
- 6. Make sure no foreign objects are left in the unit after finishing installation.

Refrigerant Safety Precautions:

- 1. Avoid contact between refrigerant and fire as it generates poisonous gas; Prohibit prolong the connection pipe by welding.
- 2. Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture or other hazards.
- 3. Make sure no refrigerant gas is leaking out when installation is completed.
- 4. If there is refrigerant leakage, please take sufficient measure to minimize the density of refrigerant.
- 5. Never touch the refrigerant piping or compressor without wearing glove to avoid scald or frostbite.

Improper installation may lead to fire hazard, explosion, electric shock or injury.


Main Tools for Installation and Maintenance




8. Installation

8.1 Installation Dimension Diagram

Installation dimension diagram



Installation procedures



Note: this flow is only for reference; please find the more detailed installation steps in this section.

8.2 Installation Parts-checking

No.	Name	No.	Name
1	Indoor unit	8	Sealing gum
2	Outdoor unit	9	Wrapping tape
3	Connection nine	10	Support of outdoor
	Connection pipe	10	unit
4	Drainage pipe	11	Fixing screw
5	Wall-mounting	12	Drainage plug(cooling
5	frame	12	and heating unit)
6 Connecting		13	Owner's manual,
	cable(power cord)	13	remote controller
7	Wall pipe		

Note:

- 1.Please contact the local agent for installation.
- 2.Don't use unqualified power cord.

8.3 Selection of Installation Location

1. Basic Requirement:

Installing the unit in the following places may cause malfunction. If it is unavoidable, please consult the local dealer:

- (1) The place with strong heat sources, vapors, flammable or explosive gas, or volatile objects spread in the air.
- (2) The place with high-frequency devices (such as welding machine, medical equipment).
- (3) The place near coast area.
- (4) The place with oil or fumes in the air. in the air.
- (5) The place with sulfureted gas.
- (6) Other places with special circumstances.

2. Indoor Unit:

- (1) There should be no obstruction near air inlet and air outlet.
- (2) Select a location where the condensation water can be dispersed easily and won't affect other people.
- (3) Select a location which is convenient to connect the outdoor unit and near the power socket.
- (4) Select a location which is out of reach for children.
- (5) The location should be able to withstand the weight of indoor unit and won't increase noise and vibration.
- (6) The height of indoor unit should be between 230-260cm from the floor in order to provide sufficient space for maintenance.
- (7) Don't install the indoor unit right above the electric appliance.
- (8) The appliance shall not be installed in the laundry

8.4 Requirements Forelectric Connection

1. Safety precaution

- (1) Must follow the electric safety regulations when installing the unit.
- (2) According to the local safety regulations, use qualified power supply circuit and air switch.
- (3) Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring may result in electric shock, fire hazard or malfunction. Please install proper power supply cables before using the air conditioner.
- (4) Properly connect the live wire, neutral wire and grounding wire of power socket.
- (5) Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- (6) Do not put through the power before finishing installation.
- (7) For appliances with type Y attachment, the instructions shall contain the substance of the following. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- (8) The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.

2. Grounding requirement:

- (1) The air conditioner is first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- (2) The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- (3) The grounding resistance should comply with national electric safety regulations.
- (4) The appliance must be positioned so that the plug is accessible
- (5) An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- (6) Including an air switch with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)

8.5 Installation of Indoor Unit

1. Choosing Installation location


Recommend the installation location to the client and then confirm it with the client.

2. Install Wall-mounting Frame


- (1) Hang the wall-mounting frame on the wall; adjust it in horizontal position with the level meter and then point out the screw fixing holes on the wall.
- (2) Drill the screw fixing holes on the wall with impact drill (the specification of drill head should be the same as the plastic expansion particle) and then fill the plastic expansion particles in the holes.
- (3) Fix the wall-mounting frame on the wall with tapping screws (ST4.2X25TA) and then check if the frame is firmly installed by pulling the frame. If the plastic expansion particle is loose, please drill another fixing hole nearby.

3. Install Wall-mounting Frame

(1) Choose the position of piping hole according to the direction of outlet pipe. The position of piping hole should be a little lower than the wall-mounted frame.(As show in Fig.1)



(2) Open a piping hole with the diameter of Φ 55 or Φ 70 on the selected outlet pipe position.In order to drain smoothly, slant the piping hole on the wall slightly downward to the outdoor side with the gradient of 5-10°.(As show in Fig.2)



∧ Note:


(1) Pay attention to dust prevention and take relevant safety measures when opening the


hole

(2) The plastic expansion particles are not provided and should be bought locally.

4. Outlet pipe


- (1) The pipe can be led out in the direction of right, rear right, left or rear left.(As show in Fig.3)
- (2) When selecting leading out the pipe from left or right, please cut off the corresponding hole on the bottom case.(As show in Fig.4)





5. Connect the Pipe of Indoor Unit

- (1) Aim the pipe joint at the corresponding bellmouth.(As show in Fig.5)
- (2) Pretightening the union nut with hand.
- (3) Adjust the torque force by referring to the following sheet. Place the open-end wrench on the pipe joint and place the torque wrench on the union nut. Tighten the union nut with torque wrench.(As show in Fig.6)
- (4) Wrap the indoor pipe and joint of connection pipe with insulating pipe, and then wrap it with tape.(As show in Fig.7)




Refer to the following table for wrench moment of force:

Hex nut diameter(mm)	Tightening torque(N.m)
Ф6	15~20
Ф9.52	30~40
Ф12	45~55
Ф16	60~65
Ф19	70~75


6. Install Drain Hose

- (1) Connect the drain hose to the outlet pipe of indoor unit.(As show in Fig.8) $\,$
- (2) Bind the joint with tape.(As show in Fig.9)




Note:

- (1) Add insulating pipe in the indoor drain hose in order to prevent condensation.
- (2) The plastic expansion particles are not provided. (As show in Fig.10)




7. Connect Wire of Indoor Unit


(1) Open the panel, remove the screw on the wiring cover and then take down the cover.(As show in Fig.11)



(2) Make the power connection wire go through the cable-cross hole at the back of indoor unit and then pull it out from the front side.(As show in Fig.12)



(3) Remove the wire clip; connect the power connection wiresignal control wire(only for cooling and heating unit) to the wiring terminal according to the color; tighten the screw and then fix the power connection wire with wire clip.(As show in Fig.13)



Note: The wiring connect is for reference only, please refer to the actual one

Fig.13


- (4) Put wiring cover back and then tighten the screw.
- (5) Close the panel.


⚠ Note:

- (1) All wires of indoor unit and outdoor unit should be connected by a professional.
- (2) If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.
- (3) For the air conditioner with plug, the plug should be reachable after finishing installation.
- (4) For the air conditioner without plug, an air switch must be installed in the line. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.

8. Bind up Pipe

- (1) Bind up the connection pipe, power cord and drain hose with the band.(As show in Fig.14)
- (2) Reserve a certain length of drain hose and power cord for installation when binding them. When binding to a certain degree, separate the indoor power and then separate the drain hose.(As show in Fig.15)
- (3) Bind them evenly.
- (4) The liquid pipe and gas pipe should be bound separately at the end





∕ Note:


- (1) The power cord and control wire can't be crossed or winding.
- (2) The drain hose should be bound at the bottom.

9. Hang the Indoor Unit

- (1) Put the bound pipes in the wall pipe and then make them pass through the wall hole.
- (2) Hang the indoor unit on the wall-mounting frame.
- (3) Stuff the gap between pipes and wall hole with sealing gum.
- (4) Fix the wall pipe.

(As show in Fig.16)

(5) Check if the indoor unit is installed firmly and closed to the wall.(As show in Fig.17)



Note: ∧

Do not bend the drain hose too excessively in order to prevent blocking.

8.6 Check after Installation and Test Operation

1. Check after Installation

Check according to the following requirement after finishing installation.

NO.	Items to be checked	Possible malfunction
1	Has the unit been	The unit may drop, shake or
'	installed firmly?	emit noise.
2	Have you done the	It may cause insufficient cooling
	refrigerant leakage test?	(heating) capacity.
3	Is heat insulation of	It may cause condensation and
	pipeline sufficient?	water dripping.
4	Is water drained well?	It may cause condensation and
	is water drained weir:	water dripping.
	Is the voltage of power	
5	supply according to the	It may cause malfunction or
"	voltage marked on the	damage the parts.
	nameplate?	
	Is electric wiring and	It may cause malfunction or
6	pipeline installed	damage the parts.
	correctly?	damago trio parto.
7	Is the unit grounded	It may cause electric leakage.
Ľ.	securely?	, ,
8	Does the power cord	It may cause malfunction or
	follow the specification?	damage the parts.
9	Is there any obstruction	It may cause insufficient cooling
	in air inlet and air outlet?	(heating).
	The dust and	
10	sundries caused	It may cause malfunction or
'	during installation are	damaging the parts.
	removed?	
	The gas valve and liquid	It may cause insufficient cooling
11	valve of connection pipe	(heating) capacity.
	are open completely?	(induling) dapadity.

2. Test operation

- (1) Preparation of test operation
- The client approves the air conditioner installation.
- Specify the important notes for air conditioner to the client.
- (2) Method of test operation
- Put through the power, press ON/OFF button on the remote controller to start operation.
- Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
- \bullet If the ambient temperature is lower than 16 $^\circ\!\mathbb{C}$, the air conditioner can't start cooling.

9. Maintenance

9.1 Error Code

1. Malfunction display requirement

When there are several malfunctions, they will be displayed circularly.

2. Malfunction display method

- (1) Hardware malfunction: immediate display; refer to "error code list";
- (2) Operation state: immediate display; refer to "error code list";
- (3) Other malfunctions: it is displayed after the compressor stops for 200s; refer to "error code list".

Note: when the compressor is restarted, the malfunction display delay time (200s) is cleared.

3. Malfunction display control

The indicator lamp and dual 8 nixie tube displays shall be synchronized. That is when the indicator lamp blinks, the dual 8 nixie tube displays the corresponding malfunction code.

4. Display control viaremote controller

Enter display control: press light button successively for 6 times within 3s to display the corresponding malfunction code; Exit display control: pressing light button successively for 6 times within 3s or after display is shown for 5min, the display will terminate.


Error Code List

	Malfunction types	Dual-8 Nixie Tube	Indicator Display		
Malfunction Name			Operation	Cooling	Heating
		INIXIE TUDE	indicator	indicator	indicator
Fault in input power zero	Hardware malfunction	U8	blink 17 times		
Jumper cap malfunction protection	Hardware malfunction	C5	blink 15 times		
No feedback of indoor fan motor	Hardware malfunction	H6	blink 11 times		
Indoor ambient sensor open or short circuit	Hardware malfunction	F1		blink once	
Indoor tube sensor open or short circuit	Hardware malfunction	F2		blink twice	
Inlet tube sensor malfunction	Hardware malfunction	b5		blink 19 times	
Outlet tube sensor malfunction	Hardware malfunction	b7		blink 22 times	
IPM sensor circuit malfunction	Hardware malfunction	P7			blink 18 times
Outdoor ambient sensor open or short circuit	Hardware malfunction	F3		blink 3 times	
Inlet pipe temperature sensor of outdoor condenser is open-circuit/short circuit(commercial air con)	Hardware malfunction	A5			
Outdoor tube sensor open or short circuit	Hardware malfunction	F4		blink 4 times	
outlet pipe temperature sensor of outdoor condenser is open-circuit/short circuit(commercial air con)	Hardware malfunction	A7			
Exhaust sensor open or short circuit	Hardware malfunction	F5		blink 5 times	
Communication failure between indoor unit and outdoor unit	Hardware malfunction	E6	blink 6 times		
Compressor phase current detection circuit malfunction	Hardware malfunction	U1			blink 12 times
Compressor demagnetization protection	It can be displayed	HE			blink 14 times
PN voltage drop protection	through remote	U3			blink 20 times
IPM high temperature protection	controller within 200s	P8			blink 19 times
Refrigerant-lacking or blockage protection	and displayed directly after 200s	F0		blink 10 times	
Capacitor charge malfunction	Hardware malfunction	PU			blink 17 times
Refrigerant system high pressure protection	Hardware malfunction	E1	blink once		
system low-pressure protection (reserved)	Hardware malfunction	E3	blink 3 times		
Compressor over load protection	It can be displayed through remote controller within 200s and displayed directly after 200s	Н3			blink 3 times
Fault in matching	Hardware malfunction	LP	blink 19 times		
Loading EEPROM malfunction	Hardware malfunction	EE			blink 15 times
AC current detect circuit malfunction	Hardware malfunction	U5		blink 13 times	
Outdoor DC fan motor malfunction	Hardware malfunction	L3	blink 23 times		


Mode conflict	operation status	E7	blink 7 times		
Recovery refrigerant mode	operation status	Fo	blink once	blink once	
X-fan	operation status			ON for 0.5s and OFF for 10s	
Defrosting or oil return in heating	operation status				OFF for 0.5s and ON for 10s
Startup failure		Lc			blink 11 times
Compressor exhaust high temperature protection		E4	blink 4 times		
Anti-high temperature protection	It can be displayed	E8	blink 8 times		
AC over-current protection		E5	blink 5 times		
Over compressor phase current protection		P5			blink 15 times
Compressor loss step protection	through remote	H7			blink 7 times
Compressor loss of phase protection	controller within 200s	Ld			
IPM protection	and displayed directly after 200s	H5			blink 5 times
Low PN voltage protection		PL			blink 21 times
Over voltage protection for PN		PH		blink 11 times	
PFC protection		HC			blink 6 times
4-way valve reversal abnormal		U7		blink 20 times	

9.2 Procedure of Troubleshooting


1. Malfunction of Temperature Sensor F1, F2




2. Malfunction of Blocked Protection of IDU Fan Motor H6




3. Malfunction of Protection of Jumper Cap C5




4. Malfunction of Zero-crossing Inspection Circuit Malfunction of the IDU Fan Motor U8




5. E6 Malfunction





10. Exploded View and Parts' List


MUPR-07-H3M CL20820



MUPR-07-H3M CL20820

Nº	Description	Qty	Supplier Ref.	Code
1	Receiver Window	0	none	
2	Front panel assy	1	2001217601	
3	Filter Sub-Assy	2	11122081	
4	Screw Cover	3	24252016	
5	Front Case	1	20012120C	
6	Swing Louver	1	10512114	
7	Air Louver 1	1	10512113	
8	Helicoid tongue	1	26112162	
9	Axile Bush	1	10542704	
10	Rear Case assy	1	2220210111	
11	Water Tray Glue Plug	1	76712012	
	Ring of Bearing	1	26152022	
13	O-Gasket sub-assy of Bearing	1	76512051	
	Cross Flow Fan (Turbina ventilador)	1	10352043	CL96178
	Remote Controller (Control remoto)	1	305100492	CL98052
	Ambient Temperature Sensor (Sensor de temp. ambiente)	1	390000453	CL98666
	Temperature Sensor (Sensor de temperatura de tubería)	1	390000599	CL96179
	Connecting Cable	0	4002052317	
	Evaporator Support	1	24212090	
	Evaporator Assy	1	0100274301	
	Wall-Mounting Frame	1	01252015	
	Motor Press Plate	1	26112160	
	Fan Motor (Motor ventilador)	1	15012115	CL98658
	Pipe Clamp	1	26112164	
	Drainage hose	1	0523001406	
	Step Motor (Motor lamas)	1	1521212901	CL96180
	Crank	1	10582070	
	Receiver Board D5183B (Placa receptora)	1	30565012	CL96181
	Guide Louver1	1	10512111	
30	Axile Bush	1	10542036	
	Electric Box	1	2011216701	
	Terminal Board	1	42011233	
	Capacitor CBB61	1	33010002	
	Electric Box Cover2	1	20122075	
	Jumping Connector	1	4202300101	
	Main Board (Placa electrónica)	1	30148874	CL96682
	Shield cover of Electric Box sub-assy	1	0159207301	
	Electric Box Cover1	1	22242135	
	Electric Box Assy	1	20402551	
	Cold Plasma Generator	1	1114001602	


MUPR-09-H3M CL20821



MUPR-09-H3M CL20821

Ν°	Description	Qty	Supplier Ref.	Code
1	Receiver Window	0	none	
2	Front panel assy	1	2001217601	
3	Filter Sub-Assy	2	11122081	
4	Screw Cover	3	24252016	
5	Front Case	1	20012120C	
6	Swing Louver	1	10512114	
7	Air Louver 1	1	10512113	
8	Helicoid tongue	1	26112162	
9	Axile Bush	1	10542704	
10	Rear Case assy	1	2220210111	
11	Water Tray Glue Plug	1	76712012	
12	Ring of Bearing	1	26152022	
13	O-Gasket sub-assy of Bearing	1	7651205102	
14	Cross Flow Fan (Turbina ventilador)	1	10352043	CL96178
15	Remote Controller (Control remoto)	1	305100492	CL98052
16	Ambient Temperature Sensor (Sensor de temp. ambiente)	1	390000453	CL98666
17	Temperature Sensor (Sensor de temperatura de tubería)	1	390000599	CL96179
18	Connecting Cable	0	4002052317	
19	Evaporator Support	1	24212090	
20	Evaporator Assy	1	0100274301	
21	Wall-Mounting Frame	1	01252015	
22	Motor Press Plate	1	26112160	
23	Fan Motor (Motor ventilador)	1	15012115	CL98658
24	Pipe Clamp	1	26112164	
25	Drainage hose	1	0523001406	
26	Step Motor (Motor lamas)	1	1521212901	CL96180
27	Crank	1	10582070	
28	Receiver Board D5183B (Placa receptora)	1	30565012	CL96181
29	Guide Louver1	1	10512111	
30	Axile Bush	1	10542036	
31	Electric Box	1	2011216701	
32	Terminal Board	1	42011233	
	Capacitor CBB61	1	33010002	
	Electric Box Cover2	1	20122075	
35	Jumping Connector	1	4202300101	
36	Main Board (Placa electrónica)	1	30148874	CL96682
37	Shield cover of Electric Box sub-assy	1	0159207301	
38	Electric Box Cover1	1	22242135	
39	Electric Box Assy	1	20402551	
40	Cold Plasma Generator	1	1114001602	


MUPR-12-H3M CL20822



MUPR-12-H3M CL20822

Nº	Description	Qty	Supplier Ref.	Code
1	Decorative Board	1	2019223601	
2	Front Panel Sub-Assy	1	20012548	
3	Filter Sub-Assy	2	1112220403	
4	Screw Cover	1	24252016	
5	Front Case Sub-Assy	1	2001213908	
6	Air Louver 2	1	10512155	
7	Air Louver 1	1	10512156	
8	Helicoid Tongue	1	26112163	
9	Left Axile Bush	1	10512037	
10	Rear Case assy	1	2220210301	
11	Water Tray Glue Plug	1	76712012	
12	Ring of Bearing	1	26152022	
13	O-Gasket sub-assy of Bearing	1	76512051	
14	Cross Flow Fan (Turbina ventilador)	1	10352017	CL96683
15	Remote Controller (Control remoto)	1	305100492	CL98052
16	Temperature Sensor (Sensor de temperatura de tubería)	1	390000599	CL96179
17	Ambient Temperature Sensor (Sensor de temp. ambiente)	1	390000453	CL98666
18	Connecting Cable	0	4002052317	
19	Evaporator Support	1	24212091	
20	Evaporator Assy	1	0100274401	
	Wall Mounting Frame	1	01252021	
22	Motor Press Plate	1	26112161	
23	Motor FN20J-PG (Motor ventilador)	1	150120874	CL98660
24	Pipe Clamp	1	26112164	
25	Drainage Pipe	1	0523001401	
26	Step Motor (Motor lamas)	1	1521212901	CL96180
27	Crank	1	10582070	
28	Receiver Board D5183B (Placa receptora)	1	30565012	CL96181
29	Guide Louver	1	10512157	
30	Axile Bush	1	10542036	
31	Electric Box	1	2011216701	
32	Terminal Board	1	42011233	
33	Capacitor CBB61	1	33010002	
34	Electric Box Cover2	1	20122075	
35	Jumper Cap	1	4202300104	
36	Main Board (Placa electrónica)	1	30148874	CL96682
	Shield cover of Electric Box sub-assy	1	0159207301	
38	Electric Box Cover1	1	22242135	
39	Electric Box Assy	1	20402556	
	Cold Plasma Generator	1	1114001602	

MUPR-18-H3M CL20823




MUPR-18-H3M CL20823

Nº	Description	Qty	Supplier Ref.	Code
1	Decorative Board	1	20192260	
2	Front Panel Assy	1	20012280	
3	Filter Sub-Assy	2	1112208901	
4	Screw Cover	3	24252016	
5	Baffle Plate	1	26112228	
6	Front Case Sub-assy	1	20022172	
7	Air Louver 2	1	10512117	
8	Air Louver 1	1	10512116	
9	Helicoid Tongue	1	26112238	
10	Left Axile Bush	1	10512037	
11	Rear Case assy	1	12312214	
12	Water Tray Glue Plug	1	76712012	
	Ring of Bearing	1	26152022	
	O-Gasket sub-assy of Bearing	1	76512051	
15	Cross Flow Fan (Turbina ventilador)	1	10352019	CL98648
16	Remote Controller (Control remoto)	1	305100492	CL98052
17	Temperature Sensor (Sensor de temperatura de tubería)	1	390000599	CL96179
18	Ambient Temperature Sensor (Sensor de temp. ambiente)	1	390000453	CL98666
19	Connecting Cable	0	4002052317	
20	Evaporator Support	1	24212133	
21	Evaporator Assy	1	01002774	
22	Wall Mounting Frame	1	01252218	
23	Motor Press Plate	1	26112494	
24	Fan Motor (Motor ventilador)	1	15012146	CL96184
25	Pipe Clamp	1	26112164	
26	Drain Pipe	1	05230014	
27	Step Motor (Motor lamas)	1	15012086	CL96686
	Crank	1	10582070	
	Display Board (Placa display)	1	30565039	CL96186
	Guide Louver	1	10512115	
	Axile Bush	1	10542036	
	Electric Box	1	2011210801	
	Terminal Board	1	42011233	
	Capacitor CBB61	1	33010043	
	Electric Box Cover2	1	20112081	
	Jumper Cap	1	4202300108	
	Main Board (Placa electrónica)	1	30148877	CL96187
	Shield Cover of Electric Box	1	01592092	
	Electric Box Cover1	1	20122154	
40	Electric Box Assy	1	20402557	
	Cold Plasma Generator	1	1114001602	

11. Removal Procedure

Caution: discharge the refrigerant completely before removal.



Step **Procedure** 3. Remove panel Panel Open the front panel; separate the panel Front panel rotation shaft from the groove fixing the front panel and then removes the front panel. Note: Panel rotation The display of some models is fixed on the panel; unscrew the screws fixing the display on the panel before removing the Groove 4. Remove electric box cover Remove the screws on the electric box cover to remove the electric box cover. Screws Electric box cover 5. Remove front case sub-assy Screws Remove the screws fixing front case. а Note: 1. Open the screw caps before removing the screws around the air outlet. Front case 2. The quantity of screws fixing the front sub-assy Screw caps case sub-assy is different for different models. Left clasp Middle clasp Right clasp Front case Loosen the clasps at left, middle and right b sub-assy sides of front case. Life the front case sub-assy upwards to remove it.

Step **Procedure** 6. Remove vertical louver Loosen the connection clasps between vertical louver and bottom case to remove vertical louver. **Bottom** case Vertical louver Clasps 7. Remove electric box assy а Loosen the connection clasps between shield cover of electric box sub-assy and electric box, and then remove the shield cover of electric box sub-assy. Electric box Shield cover of electric Clasps box sub-assy Cut off the tieline which binding the b temperature sensor and grounding wire on the evaporator, and then pull out the indoor tube temperature sensor from the evaporator. Remove the screws at the connection place between grounding wire and Temperature sensor evaporator. Pull out the wiring terminal of motor and Grounding wire wiring terminal of step motor from the mainboard. Wiring Evaporator terminal Note: of motor 1.Location of tube temperature sensor and tieline on the evaporator is different for different models. Location of grounding 2. When pulling out the wiring terminal, wire screw pay attention to loose the clasp and don't pull it so hard. Wiring terminal of step motor

Step		Procedure
С	Remove two screws fixing display. Note: The display of some models is fixed on the panel; unscrew the screws fixing the display on the panel before removing the panel.	Screws Display
d	Remove the screw fixing electric box assy and then remove the electric box assy.	Screws
8. Rer	nove evaporator assy	Connection pipe clamp
а	At the back of the unit, remove the screw fixing connection pipe clamp and then remove the connection pipe clamp.	Screws
b	Remove 3 screws fixing evaporator assy.	Evaporator assy Screws
С	Adjust the position of connection pipe on evaporator slightly and then lift the evaporator upwards to remove it.	Connection pipe

Step		Procedure
9. Re	emove stepping motor	Step motor
	Remove the screw fixing step motor and then remove the step motor.	Screws
10. F	Remove motor and cross flow blade	
а	Remove the screws fixing motor clamp and then remove the motor clamp.	Motor clamp
b	Remove the screws at the connection place of cross flow blade and motor; lift the motor and cross flow blade upwards to remove them.	Cross flow Motor Screws
С	Remove the bearing holder sub-assy.	Holder sub-assy O O O O O O O O O O O O O

Appendix:

Appendix 1: Reference Sheet of Celsius and Fahrenheit

Conversion formula for Fahrenheit degree and Celsius degree: Tf=Tcx1.8+32 Set temperature

Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)		Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature	Fahrenheit (°F)	Celsius (℃)
61	60.8	16]	69/70	69.8	21	78/79	78.8	26
62/63	62.6	17]	71/72	71.6	22	80/81	80.6	27
64/65	64.4	18]	73/74	73.4	23	82/83	82.4	28
66/67	66.2	19		75/76	75.2	24	84/85	84.2	29
68	68	20		77	77	25	86	86	30

Ambient temperature

ioni tomporati								
Fahrenheit display temperature	Fahrenheit (°F)	Celsius(°C)	Fahrenheit display temperature	Fahrenheit (°F)	Celsius (℃)	Fahrenheit display temperature	Fahrenheit	Celsius (°C)
32/33	32	0	55/56	55.4	13	79/80	78.8	26
34/35	33.8	1	57/58	57.2	14	81	80.6	27
36	35.6	2	59/60	59	15	82/83	82.4	28
37/38	37.4	3	61/62	60.8	16	84/85	84.2	29
39/40	39.2	4	63	62.6	17	86/87	86	30
41/42	41	5	64/65	64.4	18	88/89	87.8	31
43/44	42.8	6	66/67	66.2	19	90	89.6	32
45	44.6	7	68/69	68	20	91/92	91.4	33
46/47	46.4	8	70/71	69.8	21	93/94	93.2	34
48/49	48.2	9	72	71.6	22	95/96	95	35
50/51	50	10	73/74	73.4	23	97/98	96.8	36
52/53	51.8	11	75/76	75.2	24	99	98.6	37
54	53.6	12	77/78	77	25			

Appendix 2: Configuration of Connection Pipe

- 1.Standard length of connection pipe
- 5m, 7.5m, 8m.
- 2.Min. length of connection pipe is 3m.
- 3.Max. length of connection pipe and max. high difference.
- 4. The additional refrigerant oil and refrigerant charging required after prolonging connection pipe
- After the length of connection pipe is prolonged for 10m at the basis of standard length, you should add 5ml of refrigerant oil for each additional 5m of connection pipe.
- The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):

5000 Btu/h(1465 W) 15 m 5 m 7000 Btu/h(2051 W) 15 m 5 m 9000 Btu/h(2637 W) 15 m 10 m 12000 Btu/h(3516 W) 20 m 10 m 18000 Btu/h(5274 W) 25 m 10 m 24000 Btu/h(7032 W) 25 m 10 m 28000 Btu/h(8204 W) 30 m 10 m 36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m 48000 Btu/h(14064 W) 30 m 20 m	Cooling capacity	Max length of connection pipe	Max height difference
9000 Btu/h(2637 W) 15 m 10 m 12000 Btu/h(3516 W) 20 m 10 m 18000 Btu/h(5274 W) 25 m 10 m 24000 Btu/h(7032 W) 25 m 10 m 28000 Btu/h(8204 W) 30 m 10 m 36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m	5000 Btu/h(1465 W)	15 m	5 m
12000 Btu/h(3516 W) 20 m 10 m 18000 Btu/h(5274 W) 25 m 10 m 24000 Btu/h(7032 W) 25 m 10 m 28000 Btu/h(8204 W) 30 m 10 m 36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m	7000 Btu/h(2051 W)	15 m	5 m
18000 Btu/h(5274 W) 25 m 10 m 24000 Btu/h(7032 W) 25 m 10 m 28000 Btu/h(8204 W) 30 m 10 m 36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m	9000 Btu/h(2637 W)	15 m	10 m
24000 Btu/h(7032 W) 25 m 10 m 28000 Btu/h(8204 W) 30 m 10 m 36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m	12000 Btu/h(3516 W)	20 m	10 m
28000 Btu/h(8204 W) 30 m 10 m 36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m	18000 Btu/h(5274 W)	25 m	10 m
36000 Btu/h(10548 W) 30 m 20 m 42000 Btu/h(12306 W) 30 m 20 m	24000 Btu/h(7032 W)	25 m	10 m
42000 Btu/h(12306 W) 30 m 20 m	28000 Btu/h(8204 W)	30 m	10 m
, ,	36000 Btu/h(10548 W)	30 m	20 m
48000 Btu/h(14064 W) 30 m 20 m	42000 Btu/h(12306 W)	30 m	20 m
	48000 Btu/h(14064 W)	30 m	20 m

- When the length of connection pipe is above 5m, add refrigerant according to the prolonged length of liquid pipe. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See the following sheet.
- Additional refrigerant charging amount = prolonged length of liquid pipe X additional refrigerant charging amount per meter

Additional refrigerant charging amount for R22, R407C, R410A and R134a									
Diameter of con	nection pipe	Outdoor unit throttle							
Liquid pipe(mm)	Gas pipe(mm)	Cooling only(g/m)	Cooling and heating(g/m)						
Ф6	Ф9.5 ог Ф12	15	20						
Ф6 ог Ф9.5	Ф16 or Ф19	15	20						
Ф12	Ф19 or Ф22.2	30	120						
Ф16	Ф25.4 ог Ф31.8	60	120						
Ф19	/	250	250						
Ф22.2	/	350	350						


Appendix 3: Pipe Expanding Method

⚠ Note:

Improper pipe expanding is the main cause of refrigerant leakage.Please expand the pipe according to the following steps:

A:Cut the pip

- Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- Cut the required pipe with pipe cutter.



B:Remove the burrs


• Remove the burrs with shaper and prevent the burrs from getting into the pipe.

C:Put on suitable insulating pipe



D:Put on the union nut

• Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.




E:Expand the port

• Expand the port with expander.

⚠ Note:


• "A" is different according to the diameter, please refer to the sheet below:

Outer diameter/mm)	A(mm)						
Outer diameter(mm)	Max	Min					
Ф6 - 6.35 (1/4")	1.3	0.7					
Ф9.52 (3/8")	1.6	1.0					
Ф12 - 12.70 (1/2")	1.8	1.0					
Ф16 - 15.88 (5/8")	2.4	2.2					



F:Inspection

• Check the quality of expanding port. If there is any blemish, expand the port again according to the steps above.



Appendix 4: List of Resistance for Ambient Temperature Sensor

Appendix 1: Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(15K)

Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)
-19	138.1	20	18.75	59	3.848	98	1.071
-18	128.6	21	17.93	60	3.711	99	1.039
-17	121.6	22	17.14	61	3.579	100	1.009
-16	115	23	16.39	62	3.454	101	0.98
-15	108.7	24	15.68	63	3.333	102	0.952
-14	102.9	25	15	64	3.217	103	0.925
-13	97.4	26	14.36	65	3.105	104	0.898
-12	92.22	27	13.74	66	2.998	105	0.873
-11	87.35	28	13.16	67	2.896	106	0.848
-10	82.75	29	12.6	68	2.797	107	0.825
-9	78.43	30	12.07	69	2.702	108	0.802
-8	74.35	31	11.57	70	2.611	109	0.779
-7	70.5	32	11.09	71	2.523	110	0.758
-6	66.88	33	10.63	72	2.439	111	0.737
-5	63.46	34	10.2	73	2.358	112	0.717
-4	60.23	35	9.779	74	2.28	113	0.697
-3	57.18	36	9.382	75	2.206	114	0.678
-2	54.31	37	9.003	76	2.133	115	0.66
-1	51.59	38	8.642	77	2.064	116	0.642
0	49.02	39	8.297	78	1.997	117	0.625
1	46.6	40	7.967	79	1.933	118	0.608
2	44.31	41	7.653	80	1.871	119	0.592
3	42.14	42	7.352	81	1.811	120	0.577
4	40.09	43	7.065	82	1.754	121	0.561
5	38.15	44	6.791	83	1.699	122	0.547
6	36.32	45	6.529	84	1.645	123	0.532
7	34.58	46	6.278	85	1.594	124	0.519
8	32.94	47	6.038	86	1.544	125	0.505
9	31.38	48	5.809	87	1.497	126	0.492
10	29.9	49	5.589	88	1.451	127	0.48
11	28.51	50	5.379	89	1.408	128	0.467
12	27.18	51	5.197	90	1.363	129	0.456
13	25.92	52	4.986	91	1.322	130	0.444
14	24.73	53	4.802	92	1.282	131	0.433
15	23.6	54	4.625	93	1.244	132	0.422
16	22.53	55	4.456	94	1.207	133	0.412
17	21.51	56	4.294	95	1.171	134	0.401
18	20.54	57	4.139	96	1.136	135	0.391
19	19.63	58	3.99	97	1.103	136	0.382

Appendix 1: Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(20K)

Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	mp(°C) Resistance(kΩ)		Temp(°C)	Resistance(kΩ)
-19	181.4	20	25.01	59	5.13		98	1.427
-18	171.4	21	23.9	60	4.948		99	1.386
-17	162.1	22	22.85	61	4.773		100	1.346
-16	153.3	23	21.85	62	4.605		101	1.307
-15	145	24	20.9	63	63 4.443		102	1.269
-14	137.2	25	20	64	4.289		103	1.233
-13	129.9	26	19.14	65	4.14		104	1.198
-12	123	27	18.13	66	3.998		105	1.164
-11	116.5	28	17.55	67	3.861		106	1.131
-10	110.3	29	16.8	68	3.729		107	1.099
-9	104.6	30	16.1	69	3.603		108	1.069
-8	99.13	31	15.43	70	3.481		109	1.039
-7	94	32	14.79	71	3.364		110	1.01
-6	89.17	33	14.18	72	3.252		111	0.983
-5	84.61	34	13.59	73	3.144		112	0.956
-4	80.31	35	13.04	74	3.04		113	0.93
-3	76.24	36	12.51	75	2.94		114	0.904
-2	72.41	37	12	76	2.844		115	0.88
-1	68.79	38	11.52	77	2.752		116	0.856
0	65.37	39	11.06	78	2.663		117	0.833
1	62.13	40	10.62	79	2.577		118	0.811
2	59.08	41	10.2	80	2.495		119	0.77
3	56.19	42	9.803	81	2.415		120	0.769
4	53.46	43	9.42	82	2.339		121	0.746
5	50.87	44	9.054	83	2.265		122	0.729
6	48.42	45	8.705	84	2.194		123	0.71
7	46.11	46	8.37	85	2.125		124	0.692
8	43.92	47	8.051	86	2.059		125	0.674
9	41.84	48	7.745	87	1.996		126	0.658
10	39.87	49	7.453	88	1.934		127	0.64
11	38.01	50	7.173	89	1.875		128	0.623
12	36.24	51	6.905	90	1.818		129	0.607
13	34.57	52	6.648	91	1.736		130	0.592
14	32.98	53	6.403	92	1.71		131	0.577
15	31.47	54	6.167	93	1.658		132	0.563
16	30.04	55	5.942	94	1.609		133	0.549
17	28.68	56	5.726	95	1.561		134	0.535
18	27.39	57	5.519	96	1.515		135	0.521
19	26.17	58	5.32	97	1.47		136	0.509

Appendix 1: Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(50K)

Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)	Temp(°C)	Resistance(kΩ)
-29	853.5	10	98	49	18.34	88	4.75
-28	799.8	11	93.42	50	17.65	89	4.61
-27	750	12	89.07	51	16.99	90	4.47
-26	703.8	13	84.95	52	16.36	91	4.33
-25	660.8	14	81.05	53	15.75	92	4.20
-24	620.8	15	77.35	54	15.17	93	4.08
-23	580.6	16	73.83	55	14.62	94	3.96
-22	548.9	17	70.5	56	14.09	95	3.84
-21	516.6	18	67.34	57	13.58	96	3.73
-20	486.5	19	64.33	58	13.09	97	3.62
-19	458.3	20	61.48	59	12.62	98	3.51
-18	432	21	58.77	60	12.17	99	3.41
-17	407.4	22	56.19	61	11.74	100	3.32
-16	384.5	23	53.74	62	11.32	101	3.22
-15	362.9	24	51.41	63	10.93	102	3.13
-14	342.8	25	49.19	64	10.54	103	3.04
-13	323.9	26	47.08	65	10.18	104	2.96
-12	306.2	27	45.07	66	9.83	105	2.87
-11	289.6	28	43.16	67	9.49	106	2.79
-10	274	29	41.34	68	9.17	107	2.72
-9	259.3	30	39.61	69	8.85	108	2.64
-8	245.6	31	37.96	70	8.56	109	2.57
-7	232.6	32	36.38	71	8.27	110	2.50
-6	220.5	33	34.88	72	7.99	111	2.43
-5	209	34	33.45	73	7.73	112	2.37
-4	198.3	35	32.09	74	7.47	113	2.30
-3	199.1	36	30.79	75	7.22	114	2.24
-2	178.5	37	29.54	76	7.00	115	2.18
-1	169.5	38	28.36	77	6.76	116	2.12
0	161	39	27.23	78	6.54	117	2.07
1	153	40	26.15	79	6.33	118	2.02
2	145.4	41	25.11	80	6.13	119	1.96
3	138.3	42	24.13	81	5.93	120	1.91
4	131.5	43	23.19	82	5.75	121	1.86
5	125.1	44	22.29	83	5.57	122	1.82
6	119.1	45	21.43	84	5.39	123	1.77
7	113.4	46	20.6	85	5.22	124	1.73
8	108	47	19.81	86	5.06	125	1.68
9	102.8	48	19.06	87	4.90	126	1.64



ASK FOR MORE INFORMATION:

Phone: 93 446 27 80 - Fax: 93 456 90 32 eMail: mundoclima@salvadorescoda.com

TECHNICAL ASSISTANCE:

Phone: 93 652 53 57 - Fax: 93 635 45 08