

INDOOR UNITS MVD D4+

Owner's manual



CONTENTS	PAGE
IMPORTANT SAFETY INFORMATION.....	1
PARTS NAMES.....	3
AIR CONDITIONER OPERATIONS AND PERFORMANCE.....	6
ADJUSTING AIR FLOW DIRECTION.....	7
MAINTENANCE.....	11
FOLLOWING SYMPTOMS ARE NOT AIR CONDITIONER TROUBLES.....	14
TROUBLESHOOTING.....	15
REMOTE CONTROLLER.....	17
WIRELESS REMOTE CONTROLLER RM05.....	17
WIRELESS REMOTE CONTROLLER RM02A.....	20
WIRED REMOTE CONTROLLER KJR-29B.....	23

1. Important safety information

To prevent injury to the user or other people and property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage.

The safety precautions listed are divided into two categories. In either case, important safety information is listed which must be read.



WARNING

Failure to observe a warning may result in death. The appliance shall be installed in accordance with national wiring regulations.



CAUTION

Failure to observe a caution may result in injury or damage to the equipment.



WARNING

Ask your dealer for installation of the air conditioner.
Incomplete installation performed by yourself may result in a water leakage, electric shock, and fire.

Ask your dealer for improvement, repair, and maintenance.
Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.

In order to avoid electric shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off the power supply and call your dealer for instructions.

Never let the indoor unit or the remote controller get wet.
It may cause an electric shock or a fire.

Never press the button of the remote controller with a hard, pointed object.
The remote controller may be damaged.

Never replace a fuse with that of wrong rated current or other wires when a fuse blows out.
Use of wire or copper wire may cause the unit to break down or cause a fire.

It is not good for your health to expose your body to the air flow for a long time.

Do not insert fingers, rods or other objects into the air inlet or outlet.

When the fan is rotating at high speed, it will cause injury.

Never use a flammable spray such as hair spray, lacquer or paint near the unit.

It may cause a fire.

Never touch the air outlet or the horizontal blades while the swing flap is in operation.

Fingers may become caught or the unit may break down.

Never put any objects into the air inlet or outlet.

Objects touching the fan at high speed can be dangerous.

Never inspect or service the unit by yourself.

Ask a qualified service person to perform this work.

Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
Contact your local government for information regarding the connection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

To prevent refrigerant leak, contact your dealer.

When the system is installed and runs in a small room, it is required to keep the concentration of the refrigerant, if by any chance coming out, below the limit. Otherwise, oxygen in the room may be affected, resulting in a serious accident.

The refrigerant in the air conditioner is safe and normally does not leak.

If the refrigerant leaks in the room, contact with a fire of a burner, a heater or a cooker may result in a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do not use the air conditioner until a service person confirms that the portion where the refrigerant leaks is repaired.



CAUTION

Do not use the air conditioner for other purposes.

In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art.

Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.

Otherwise, an electric shock and injury may result.

In order to avoid electric shock or fire, make sure that an earth leak detector is installed.

Be sure the air conditioner is grounded.

In order to avoid electric shock, make sure that the unit is grounded and that the earth wire is not connected to gas or water pipe, lightning conductor or telephone earth wire.

In order to avoid injury, do not remove the fan guard of the outdoor unit.

Do not operate the air conditioner with a wet hand.
An electric shock may happen.

Do not touch the heat exchanger fins.

These fins are sharp and could result in cutting injuries.

Do not place items which might be damaged by moisture under the indoor unit.

Condensation may form if the humidity is above 80%, the drain outlet is blocked or the filter is polluted.

After a long use, check the unit stand and fitting for damage.

If damaged, the unit may fall and result in injury.

To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner.

Arrange the drain hose to ensure smooth drainage.

Incomplete drainage may cause wetting of the building, furniture etc.

Never touch the internal parts of the controller.

Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.

Never expose little children, plants or animals directly to the air flow.

Adverse influence to little children, animals and plants may result.

Do not allow a child to mount on the outdoor unit or avoid placing any object on it.

Falling or tumbling may result in injury.

Do not operate the air conditioner when using a room fumigation - type insecticide.

Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.

Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit.

It may cause incomplete combustion or deformation of the unit due to the heat.

Do not install the air conditioner at any place where flammable gas may leak out.

If the gas leaks out and stays around the air conditioner, a fire may break out.

The appliance is not intended for use by young children or infirm persons without supervision.



NOTE

All the pictures in this manual are for explanation purpose only. They may be slightly different from the air conditioner you purchased (depend on model). The actual shape shall prevail.

2. Parts names

■ Four-way cassette type




Fig.2-1

■ Ceiling-floor type




Fig.2-2

■ One-way cassette type




Fig.2-3

■ Small one-way cassette type




Fig.2-4

■ Wall-mounted type




Fig.2-5

■ Duct/ceiling type




Fig.2-6

■ High static pressure duct type




Fig.2-7




Fig.2-8

■ (Thin) Duct/ceiling type




Fig.2-9




Fig.2-10

■ Middle static pressure duct type




Fig.2-11

■ Low static pressure type




Fig.2-12

■ Console type




Fig.2-13

■ Floor Standing type

● Exposed Floor Standing (Version I)

Vertical unit with casing, with air intake from front and air outlet on top, for installation on a wall or on feet on the floor.




Fig.2-14

● Exposed Floor Standing (Version II)

Vertical unit with casing, with air intake from below and air outlet on top, for installation on a wall or on feet on the floor.






Fig.2-15

● Concealed Floor Standing (Version III)

Vertical unit for building-in, with air intake from below and air delivery at the top, for installation on a wall.



■ Two-way cassette type



3. Air conditioner operations and performance

Use the system in the following temperature for safe and effective operation. The Max operation temperature for the air conditioner.(Cooling/Heating/Dry)

Table 3-1

Temperature Mode	Outdoor temperature	Room temperature
Cooling operation	21 °C ~ 43 °C	17 °C ~ 32 °C
Heating operating	-5 °C ~ 24 °C	≤27°C (All models)
		0 °C ~ 30°C (Wall mounted)
Dry operation	11 °C ~ 43 °C	17 °C ~ 30 °C




NOTE

- 1 If air conditioner is used outside the above conditions, it may cause the unit to function abnormally.
- 2 The phenomenon is normal that the surface of air conditioning may condense water when the relative larger humidity in room, please close the door and window.
- 3 Optimum performance will be achieved within these operating temperature range.
- 4 Protection device will be activated and the unit stops when the above conditions can not satisfy.

■ Please note the following correct operation for saving energy and achieve the quick and comfortable cooling/heating effects.

- The blocked air filter will reduce cooling/heating effects.



- Close the door/window

Do not let the heat/cool air leak from the door/window.



- Do not overcool or overheat.

Do not expose you to the cool wind for a long time. Over-cool is harm to your health. Especially for the handicapped, children or older.



- **To maintain the comfortable temperature.**

Adjust the air-out direction with using the air-out louver.



4. Adjusting air flow direction

Because cold air flow down and hot air flow up, to improve the the cooling and heating effect, please adjust air flow louver direction, in result the temperature of the room will be natural and equal and you will fell more comfortable.



NOTE

- 1 The heating operation with horizontal air outlet will increase the difference of the room temperature.
- 2 The louver direction :
Choose horizontal outlet mode when cooling operation
When the cooling operation, the air flow down will cause condensing dew on the air outlet and louver surface.

■ Four-way cassette type

- **Cooling operation**

Adjust the louver horizontally .



Fig.4-1

- **Heating operation**

Adjust the louver down.




Fig.4-2

■ One-way cassette type

- **Adjust the air direction up and down**

- **Auto-swing**

Press SWING button, the louver will swing up and down.

Maximum air circulation area




Fig.4-3

- **When cooling**

Adjust the louver horizontally.




Fig.4-4

- **When heating**

Adjust the louver down(vertically).




Fig.4-5

- **Adjust the air direction left and right**

Adjust the blade inside the air outlet louver to the expected direction.

When the air flow sideways and the air flow parts must be used (sold separately), please refer to the following figures to adjust the air flow direction.

- **Adjust the air flow up and down**

- **Cooling operation**

Adjust the louver horizontally .




Fig.4-6

- **When heating**

Adjust the louver down(vertically).





Fig.4-7


**NOTE**

- 1 Please adjust the horizontal louver down when the air flow is down.




Horizontal louver

- 2 The slant angle of horizontal louver must be Less than 40° otherwise the water drop will be caused.



Less than 40°

- **Adjust left and right**




vertical louver

Fig.4-8

**NOTE**

When adjusting air flow left /right, refer to the following figures to turn the vertical louver to certain angles, and the angle isn't too big, otherwise the water drop will be caused.



vertical louver

- **Duct-ceiling type**

The following is how to adjust the air flow direction when the air outlet parts (sold separately) is used with the indoor unit.

- **When cooling**

To effectively heat the bottom of the room please set the louver downwards. (Fig.4-9)

- **When heating**

To effectively heat the bottom of the room please set the louver downwards. (Fig.4-10)




Fig.4-9




Fig.4-10

- **Wall-Mounted type**

Adjust the Air Flow Direction Up and Down

- **Auto-swing**

Press SWING button, the louver will swing up and down automatically.



Fig.4-11

- **Manual swing**

Adjust the louver to achieve the better cooling/ heating effects when cooling/heating.

- **When cooling**

Adjust the louver horizontally.




Fig.4-12

- **When heating**

Adjust the louver downwards (vertically).




Fig.4-13



CAUTION

- 1 Water drop may be caused on the surface of the unit or horizontal louver when cooling while the air-out direction is vertically down.
- 2 Indoor temperature will not be even on the heating mode when the air-out direction is horizontal.
- 3 Do not move the horizontal louver with hands, or malfunction may occur. Adjust it with the swing button on the wire controller.

■ Ceiling-floor type

● Auto-swing

Press SWING button, the louver will swing up and down (left and right) automatically.




Fig.4-14

● Manual swing

Adjust the louver to achieve the better cooling/ heating effects when cooling/heating.

● When cooling

Adjust the louver horizontally.




Fig.4-15

● When heating

Adjust the louver downwards (vertically).




Fig.4-16

■ Console type

■ Adjust the air direction up and down

● Auto-swing

Press SWING button, the louver will swing up and down automatically.

● Manual swing

Press Air Direction button, the louver can be fixed at a desired angle. The louver swing (upward or downward) to a certain angle for each press.




Fig.4-17

● When cooling

Adjust the louver horizontally. (Refer to Fig.4-18)

● When heating

Adjust the louver downwards (vertically). (Refer to Fig.4-19)




Fig.4-18




Fig.4-19



CAUTION

Do not try to adjust the horizontal louver by hand. When adjusting by hand, the mechanism may not operate properly or condensation may drip from air outlets.

■ Adjust the air direction left and right

Hold the knob and move the louver. You will find a knob on the left-side and the right-side blades.




Fig.4-20


■ Air flow selection

Open the front panel.
How to open the front panel: (Refer to Fig.5-4).




CAUTION

Before opening the front panel, be sure to stop the operation and turn the breaker OFF.
Do not touch the metal parts on the inside of the indoor unit, as it may result in injury.


- Make air flow selection according to what suits you. (Please refer to Fig. 7-2 about the position of)
- When setting the air flow selection switch to .

Air conditioner automatically decides the appropriate blowing pattern depending on the operating mode/situation.

Table 4-1

Operating mode	COOL mode		HEAT mode	
Situation	When the room has become fully cool, or when one hour has passed since turning on the air conditioner.	At start of operation or other times when the room is not fully cooled.	At times other than below. (Normal time.)	At start or when air temperature is low.
Blowing pattern	So that air does not come into direct contact with people, air is blown upper air outlet, room temperature is equalized.		Air is blown from the upper and lower air outlets for high speed cooling during COOL mode, and for filling the room with warm air during HEAT mode.	So that air does not come into direct contact with people, air is blown upper air outlet.

During Dry mode, so that cold air does not come into direct contact with people, air is blown upper air outlet.

- When setting the air outlet selection switch to .

Regardless of the operating mode or situation, air blows from the upper air outlet.

Use this switch when you do not want air coming out of the lower air outlet. (While sleeping etc.)



CAUTION

For switching the Auto/Manual mode of the lower air outlet, one should plug off and restart the unit for mode renewing.

■ Floor standing type

Adjust the louver to achieve better cooling/heating effects when cooling/heating.




Fig.4-21

■ Two-way cassette type

● Auto-swing

Press SWING button, the louver will swing up and down automatically.




Fig.4-22

● Manual swing

Adjust the louver to achieve the better cooling/heating effects when cooling/heating.

● When cooling

Adjust the louver horizontally.




Fig.4-23

● When heating

Adjust the louver downwards (vertically).




Fig.4-24



CAUTION

Do not try to adjust the louver by hand.
When adjusting by hand, the mechanism may not operate properly or condensation may drip from air outlets.

5. Maintenance



CAUTION

- 1 Before you clean the air conditioner, be sure the power supply is off.
- 2 Check if the wiring is not broken off or disconnected.
- 3 Use a dry cloth to wipe the indoor unit and remote controller.
- 4 A wet cloth may be used to clean the indoor unit if it is very dirty.
- 5 Never use a damp cloth on the remote controller.
- 6 Do not use a chemically-treated duster for wiping or leave such material on the unit for long. it may damage or fade the surface of the unit.
- 7 Do not use benzene, thinner, polishing powder, or similar solvents for cleaning. These may cause the plastic surface to crack or deform.

■ Method for cleaning the air filter

- The air filter can prevent the dust or other particles from going inside. In case of blockage of the filter, the working efficiency of the air conditioner may greatly decrease, therefore, the filter must be cleaned once two weeks during long time using.
- If the air conditioner is positioned in a dust place, the cleaning frequency of the air filter must be increased.
- If the accumulated dust is too heavy to be cleaned, please replace the filter with a new one (the replaceable air filter is an optional fitting).

1. Take out the air-in grill

● For Four-Way Cassette Type

Push the grill switches towards the middle simultaneously as indicated in Sketch Fig.5-1. Then pull down the air-in grill. Take out the air-in grill (together with the air filter shown in Sketch Fig.5-2). Pull the air-in grill down at 45° and lift it up to take out the grill.




Fig.5-1




Fig.5-2



CAUTION

The control box cables, which are originally connected with the main body electrical terminators must be pulled off before doing as indicated above.

● For Duct/Celling Type

Push the grill switches to the arrow directions, then open the air-in grill downwards. Turn back the air filter fixing block, then take out the air-in grill.

● For One-Way Cassette Type

Remove the air-in grille, hold the air-in buckle with two hands and open the grille downwards, pull it towards inside part and push the filter buckle to remove the grille.




Fig.5-3

● For Console Type

Push the grill switches to the arrow directions, then open the air-in grill downwards. Press the claws on the right and left of the air filter down slightly, then pull upward.




Fig.5-4




Fig.5-5

Hold the tabs of the frame, and remove the claws in 4 places. (The especial function filter can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.)




Fig.5-6

• For floor standing type

The filter is housed in the lower part of the unit in versions II and III which take in air from below or from the rear. To remove the filter in versions II and III proceed as following indicated.




Fig.5-7

While it is housed in the front cowl in version I, which take in air from the front. To remove the filter in version I, proceed as following indicated.




Fig.5-8

■ Two-way cassette type

■ Take off the inhalation grating from the panel.

- 1) Upright row (non-directional) one side of the inhalation grating, and put down the other side, and then slide follow the arrow's direction refers to Fig.5-9
- 2) Loosen the hanger of the putdown side refers to Fig.5-10
- 3) Open the inhalation grating (about 45°), and remove the other side, refers to Fig.5-11




Fig.5-9




Fig.5-10




Fig.5-11

- According to the figure shown in the position and direction of arrow, press the filter and take it down. In the same way, take down the filter on the other side, and put it back after cleaning.





Fig.5-12

● For wall mounted Type



2. Dismantle the air filter.

3. Clean the air filter

The air filter can prevent the dust or other particulate from going inside. In case of blockage of the filter, the working efficiency of the air conditioner may greatly decrease.

Therefore, the filter must be cleaned once two weeks during long time usage.

Clean the air filter with vacuum cleaner or water.

- The air-in side should face up when using vacuum cleaner. (Refer to Fig.5-13)
- The air-in side should face down when using clean water. (Refer to Fig.5-14)

If the dust accumulation is too heavy, please use soft brush and natural detergent to clean it and dry in the cool place.




Fig.5-13




Fig.5-14



CAUTION

- Do not dry out the air filter under direct sunshine or with fire.
- For the one-way cassette type, the air filter should be installed before the unit body installation.

4. Re-install the air filter.

5. Install and close the air-in grill in the reverse orders of step 1 and 2 and connect the control box cables to the corresponding terminators of the main body.

■ **Maintenance before a long stop period**

(eg. at the end of the season)

Let the indoor units run in fan only operation for about half a day in order to dry the interior of the units.

Clean air filters and casings of indoor units.

Refer to "Cleaning the air filter" for details on how to proceed and make sure to install cleaned air filters back in the same position.

Turn off the unit with the "ON/OFF" button on the remote controller, then disconnect the power.



NOTE

When the power switch is connected, some energy will be consumed, even if the unit is not in operation. So please disconnect the power to save the energy.

A degree of filth will be accumulated due to certain performance after several seasons of operation. So special maintenance is advised.

Take out of the batteries from the remote controller.

■ **Maintenance after a long stop period**

(eg. at the beginning of the season)

Check and remove everything that might be blocking inlet and outlet vents of indoor units and outdoor units.

Clean air filters and casings of indoor units.

Refer to "Cleaning the air filter" for details on how to proceed and make sure to install cleaned air filters back in the same position.

Turn on the power at least 12 hours before operating the unit in order to ensure smoother operation. As soon as the power is turned on, the remote controller displays appear.

■ **Digital scroll central air conditioning auxiliary heating equipment**

In winter, due to the difference of the area and building construction, please purchase the indoor unit with auxiliary heating to enlarge the capacity.

When turning to the heat mode the air conditioner with auxiliary heating will run at the set term.

It's no install auxiliary heating equipments on site for 4-way cassette type and duct/ceiling type (with auxiliary heating).

6. Following symptoms are not air conditioner troubles

Symptom 1: The system does not operate

- The air conditioner does not start immediately after the ON/OFF button on the remote controller is pressed.
If the operation lamp lights, the system is in normal condition. To prevent overloading of the compressor motor, the air conditioner starts 3 minutes after it is turned ON.
- If the operation lamp and the "PRE-DEF indicator(cooling and heating type) or fan only indicator(cooling only type)" light, it means you choose the heating model. When just starting, if the compressor has not started, the indoor unit appears "anti cold wind" protection because of its overflow outlet temperature.

Symptom 2: Change into the fan mode during cooling mode

- In order to prevent the indoor evaporator frosting, the system will change into fan mode automatically, restore to the cooling mode after sqon.
- When the room temperature drops to the set temperature, the compressor goes off and the indoor unit changes to fan mode; when the temperature rises up, the compressor starts again. It is same in the heating mode.

Symptom 3: White mist comes out of a unit

Symptom 3.1: Indoor unit

- When humidity is high during cooling operation If the interior of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the interior of the indoor unit. Ask your dealer for details on cleaning the unit. This operation requires a qualified service person

Symptom 3.2: Indoor unit, outdoor unit

- When the system is changed over to heating operation after defrost operation Moisture generated by defrost becomes steam and is exhausted.

Symptom 4: Noise of air conditionerscooling

Symptom 4.1: Indoor unit

- A continuous low "shah" sound is heard when the system is in cooling operation or at a stop.
When the drain pump (optional accessories) is in operation, this noise is heard.
- A "pishi-pishi" squeaking sound is heard when the system stops after heating operation.
Expansion and contraction of plastic parts caused by temperature change make this noise.

Symptom 4.2: Indoor unit, outdoor unit

- A continuous low hissing sound is heard when the system is in operation.
This is the sound of refrigerant gas flowing through both indoor and outdoor units.
- A hissing sound which is heard at the start or immediately after stopping operation or defrost operation.
This is the noise of refrigerant caused by flow stop or flow change.

Symptom 4.3: Outdoor unit

- When the tone of operating noise changes.
This noise is caused by the change of frequency.

Symptom 5: Dust comes out of the unit

- When the unit is used for the first time in a long time.
This is because dust has gotten into the unit.

Symptom 6: The units can give off odours

- The unit can absorb the smell of rooms, furniture, cigarettes, etc., and then emit it again.

Symptom 7: The outdoor unit fan does not spin.

- During operation. The speed of the fan is controlled in order to optimize product operation.

7. Troubleshooting

7.1. Troubles and causes of air conditioner

If one of the following malfunctions occur, stop operation, shut off the power, and contact with your dealer.

- Remote controller receives malfunction or the button does not work well.
- A safety device such as a fuse, a breaker frequently actuates.
- Obstacles and water enter the unit.
- Water leaks from indoor unit.
- Other malfunctions.

If the system does not properly operate except the above mentioned cases or the above mentioned malfunctions is evident, investigate the system according to the following procedures. (See in Table 7-1)

Table 7-1

Symptoms	Causes	Solution
Unit does not start	<ul style="list-style-type: none"> Power failure. Power switch is off. Fuse of power switch may have burned. Batteries of remote controller exhausted or other problem of controller. 	<ul style="list-style-type: none"> Wait for the comeback of power. Switch on the power. Replace the fuse. Replace the batteries or check the controller.
Air flowing normally but completely can't cooling	<ul style="list-style-type: none"> Temperature is not set correctly. Be in 3 minutes protection of compressor. 	<ul style="list-style-type: none"> Set the temperature properly. Wait.
Units start or stop frequently	<ul style="list-style-type: none"> Refrigerant is too little or too much. Air or no concreting gas in the refrigerating circuit. Compressor is malfunction. Voltage is too high or too low. System circuit is blocked. 	<ul style="list-style-type: none"> Check leakage, and rightly recharge refrigerant. Vacuum and recharge refrigerant. Maintenance or change compressor. Install manostat. Find reasons and solution.
Low cooling effect	<ul style="list-style-type: none"> Outdoor unit and indoor unit heat exchanger is dirty. The air filter is dirty. Inlet/outlet of indoor/outdoor units is blocked. Doors and windows are open Sunlight directly shine. Too much heat resource. Outdoor temp. is too high. Leakage of refrigerant or lack of refrigerant. 	<ul style="list-style-type: none"> Clean the heat exchanger. Clean the air filter. Eliminate all dirties and make air smooth. Close doors and windows. Make curtains in order to shelter from sunshine. Reduce heat source. AC cooling capacity reduces (normal). Check leakage and rightly recharge refrigerant.
Low heating effect	<ul style="list-style-type: none"> Outdoor temperature is lower than 7°C. Doors and windows not completely closed. Leakage of refrigerant or lack of refrigerant. 	<ul style="list-style-type: none"> Use heating device. Close doors and windows. Check leakage and rightly recharge refrigerant.

7.2. Troubles and causes of remote controller

Before asking for serving or repairing, check the following points.(See in Table 7-2)

Table 7-2



Symptoms	Causes	Solution
The fan speed can not be changed.	<ul style="list-style-type: none"> Check whether the MODE indicated on the display is "AUTO" 	When the automatic mode is selected, the air conditioner will automatically change the fan speed.
	<ul style="list-style-type: none"> Check whether the MODE indicated on the display is "DRY" 	When dry operation is selected, the air conditioner automatically change the fan speed. The fan speed can be selected during "COOL", "FAN ONLY", and "HEAT".
The remote controller signal is not transmitted even when the ON/OFF button is pushed.	<ul style="list-style-type: none"> Check whether the batteries in the remote controller are exhausted. 	The power supply is off.
The TEMP. indicator does not come on.	<ul style="list-style-type: none"> Check whether the MODE indicated on the display is FAN ONLY 	The temperature cannot be set during FAN mode.
The indication on the display disappears after a lapse of time.	<ul style="list-style-type: none"> Check whether the timer operation has come to an end when the TIMER OFF is indicated on the display. 	The air conditioner operation will stop up to the set time.
The TIMER ON indicator goes off after a lapse of certain time.	<ul style="list-style-type: none"> Check whether the timer operation is started when the TIMER ON is indicated on the display. 	Up to the set time, the air conditioner will automatically start and the appropriate indicator will go off.
No receiving tone sounds from the indoor unit even when the ON/OFF button is pressed.	<ul style="list-style-type: none"> Check whether the signal transmitter of the remote controller is properly directed to the infrared signal receiver of the indoor unit when the ON/OFF button is pressed. 	Directly transmit the signal transmitter of the remote controller to the infrared signal receiver of the indoor unit, and then repeatedly push the ON/OFF button twice.

8. Remote controller



Safety precautions


The following contents are stated on the product and the operation manual, including usage, precautions against personal harm and property loss, and the methods of using the product correctly and safely. After fully understanding the following contents (identifiers and icons), read the text body and observe the following rules.


■ Identifier description

Identifier	Meaning
 Warning	Means improper handling may lead to personal death or severe injury.
 Caution	Means improper handling may lead to personal injury or property loss.
[Note]: 1. "Harm" means injury, burn and electric shock which need long-term treatment but need no hospitalization. 2. "Property loss" means loss of properties and materials.	

■ Icon description


Icon	Meaning
	It indicates forbidding. The forbidden subject-matter is indicated in the icon or by images or characters aside.
	It indicates compulsory implementation. The compulsory subject-matter is indicated in the icon or by images or characters aside.

	Warning	Delegate installation	Please entrust the distributor or professionals to install the unit. The installers must have the relevant know-how. Improper installation performed by the user without permission may cause fire, electric shock, personal injury or water leakage.
---	---------	-----------------------	---

	Usage Warning	Forbid	Do not spray flammable aerosol to the wire controller directly. Otherwise, fire may occur.
		Forbid	Do not operate with wet hands or let water enter the wire controller. Otherwise, electric shock may occur.

8.1. Wireless remote controller RM05

- This manual gives detailed description of the precautions that should be brought to your attention during operation.
 - In order to ensure correct service of the wired remote controller please read this manual carefully before using the unit.
 - For convenience of future reference, keep this manual after reading it.
- Curtain, door or the like objects will prevent the remote signal from being received by air conditioner.
- Do not get the interior of remote controller wet. It is forbidden to expose it to direct sunlight or locate it in the place with high temp.
- Malfunction may occur if infrared signal receiver on air conditioner is exposed to sunlight. Please shelter the signal receiver from sunlight with curtain.

- Please remove the nearby electronic device for they may affect the performance of remote controller. If necessary, contact the local Midea service centre or technical support centre.
- Do not put the used or different batteries into the remote controller, otherwise remote controller will fail to send signal.
- Please remove the batteries before long period unused, otherwise the remote controller may be damaged.
- If pressing the button reset the remote controller, which indicates low battery, please replace the batteries.
- If no receiving sound is heard from indoor unit or  on remote controller does not flash, please replace the batteries.
- Effective transmitting distance of remote controller is 8m, please aim the signal sending part to the receiver on air conditioner.

8.1.1. Model and specification

Model	R05/BGE
Rated voltage	3.0V(2 pieces of LR03 7# batteries)
Min voltage for sending signal of CPU	2.4V
Effective receiving distance	8m~11m
Operation condition	-5~60°C

8.1.2. Buttons and their functions





Chart 1

MODE: Once pressing, running mode will be selected in the following sequence:



NOTE: No heating mode for cool only type unit.

FAN SPEED: Fan speed will be selected in following sequence once pressing this button:



Adjust▼: Decrease the set temp. Keeping pressing will decrease the temp with 1 per 0.5s.

- ④ Adjust▲: Increase the set temp. Keeping pressing will increase the temp with 1 per 0.5s.

ON/OFF: For turning on or turning off the air conditioner.

AIR DIRECTION: Activate swing function of air deflector. Once pressing, air deflector will turn 6°. For normal operation and better cooling and heating effect, deflector will not turn to the degree which is the state of deflector when the unit is turned off. (Only available when remote controller is used with corresponding unit.)

HORIZ SWING: Activate or turn off horizontal swing function. (Only available when remote controller is used with corresponding unit.)

VERT SWING: Activate or turn off vertical swing function. (Only available when remote controller is used with corresponding unit.)

CLOCK: Display the current time. (12:00 is displayed when resetting or electrifying for the first time.) Press CLOCK for 5s, icon indicating hour will flash with 0.5s. Press it again, icon indicating minute will flash with 0.5s. ▼ and ▲ are used to adjust the figure. Setting or modification is effective only by pressing OK button to make confirmation.

TIME ON: For time ON setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjusting the figure to 0.00 will cancel time ON setting.

- ⑪ TIME OFF: For time OFF setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjust the figure to 0.00 will cancel time ON setting.

- ⑫ RESET (inner located): Press this button with a needle of 1mm to cancel the current setting and reset remote controller.

- ⑬ LOCK (inner located): Press this button with a needle of 1mm to lock or unlock the current setting.

- ⑭ OK: Used to confirm the time setting and modification.

- ⑮ COOL/HEAT (inner located): Press this button with a needle of 1mm to shift mode between COOL only and COOL&HEAT. During setting, back light will be lightened. Factory default mode is COOL & HEAT.

- ⑯ ECO: Activate or turn off economic operation mode. It is suggested to turn on this function when sleeping. (Only available when remote controller is used with corresponding unit.)

8.1.3. Names of indicators and their functions




Chart 2

Temp: Display the set temperature. Adjust temperature via ▲ and ▼. No display in this area if the unit is on FAN mode.

Transmitting display: The icon will flash once when the signal is sent by remote controller.

ON/OFF: Icon is displayed when the remote controller is turned on, or vice versa.

- ④ Running mode: Press MODE to display current running mode. AUTO, COOL, DRY, HEAT and FAN can be selected. (HEAT function is invalid for cool only type unit.)

Time: Display the current set time. Press CLOCK for 5s, icon indicating hour will flash. Press this button again, icon indicating minute will flash. ▲ and ▼ are used to adjust the figure. Setting or modification is effective only by pressing OK button to make confirmation.

Lock: The icon will be lightened or off when pressing LOCK. In locked state, all the buttons are ineffective except button LOCK.

Time ON/OFF: In the state of time ON, icon ON will be lightened, which is the same to the state of time OFF. Setting timer ON and OFF simultaneously, both icons ON and OFF are displayed.

Fan speed: Press FAN SPEED to display the current wind speed. AUTO, LOW, MED and HIGH can be selected. The default state is high fan speed for the unit without medium fan speed.

Economic operation: This icon will be lightened or off when pressing ECO button.

NOTE: All the above icons will be displayed only when the remote controller is electrified for the first time or reset.

8.1.4. Operation instructions

Install and replace batteries

- Install 2 pieces of 7# alkaline batteries.
- Slide the cover to install batteries and make sure to place them in right pole.

AUTO operation

Switch on the power and running indicator light on indoor unit flashes.

1. Press MODE to select AUTO.
2. Adjust temp via ▲ and ▼. Generally the range is 17 ~30 .
3. Press ON/OFF and running indicator light on indoor unit is lightened. Air conditioner will work on AUTO mode and fan speed is AUTO which is nonadjustable.
4. ECO is effective on AUTO operation.

COOL/HEAT/FAN operation

1. Press MODE to select COOL, HEAT or FAN.
2. Adjust temp via ▲ and ▼. Generally the range is 17 ~30 .
3. Press FAN SPEED to select AUTO, LOW, MED or HIGH.
4. Press ON/OFF and running indicator light on indoor unit is lightened. Air conditioner will work on the set mode. Stop operation via ON/OFF.

NOTE: On FAN mode, temp is nonadjustable and ECO is ineffective. Procedure 2 is omitted.

DRY operation

1. Press MODE to select DRY.
2. Adjust temp via ▲ and ▼. Generally the range is 17 ~30 .
3. Press ON/OFF and running indicator light on indoor unit is lightened. Air conditioner will work on DRY mode. Turn off the unit via ON/OFF.
4. On DRY mode, ECO and FAN SPEED are unavailable.

Timer operation

TIME ON and TIME OFF are used to turn on and turn off the unit at the set time respectively.

TIME ON operation

1. Press TIME ON, icon SET, HOUR and ON are lightened.
2. Press TIME ON again and adjust the time.
3. Keep pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour.
4. 0.5s after setting, remote controller will send TIME ON command to the unit.

TIME OFF operation

1. Press TIME OFF, icon SET, HOUR and OFF are lightened.
2. Press TIME OFF again and adjust the time.
3. Keep pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour.
4. 0.5s after setting, remote controller will send TIME OFF command to the unit.

Set TIME ON and TIME OFF simultaneously

1. Set TIME ON according to procedures 1 and 2 specified in **TIME ON operation**.
2. Set TIME OFF as the procedures 1 and 2 specified in **TIME OFF operation**.
3. If both the set time of TIME ON and TIME OFF not exceed 10 hours, time OFF operation will activated 0.5 hour later than time ON operation. If both the set time of TIME ON and TIME OFF exceed 10 hours, time OFF operation will be activated 1 hour later than time ON operation.
4. 0.5s after setting, remote controller will send TIME ON command to the unit.

Modification of timer operation

Press corresponding button and readjust the time of time ON and time OFF. Adjust the time figure to 0.00 to cancel the timer operation.

NOTE: The time set in timer operation is the relative figure based on the clock on remote controller. Adjusting clock is unavailable when TIME ON or TIME OFF is activated.

8.2. Wireless remote controller RM02A

- The outline figure on cover is for reference only, which may differ from what you purchased.
- Make sure to read chapter PRECAUTIONS before you operate the air conditioner.
- This manual is available for model RM02A/BGE-A and RM02A/BGE(T)-A.

8.2.1. Model and specification

Model	RM02A/BGE-A RM02A/BGE(T)-A
Rated voltage	3.0V(2 pieces of LR03 7# batteries)
Min voltage for sending signal of CPU	2.0V
Effective receiving distance	8m(Where is 3.0V,that will be 11m)
Operation condition	-5~60°C

8.2.2. Buttons and their functions





Fig.3-1

- ① ON/OFF: For turning on or turning off the air conditioner.
- ② 26°C: Press this button, can operate the cool mode with the setting temperature 26°C.
- ③ MODE: Once pressing, running mode will be selected in the following sequence:



④ TIMER:

Under the OFF state, press this button, TIMER ON are lightened. continue to press TIMER button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing TIMER button will increase the time by 1 hour. Adjust the TIMER ON to be "0:00" then can cancel the TIMER ON.

Under the ON state, press this button, TIMER OFF are lightened. and continue to press TIMER button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing TIMER button will increase the time by 1 hour. Adjust the TIMER OFF to be "0:00" then can cancel the TIMER OFF.

⑤ ECO: Activate or turn off economic operation mode.


⑥ ADJUST ▽ : Decrease the set temp. Keeping pressing will decrease the temp with 1°C per 0.5s.

ADJUST ▲ : Increase the set temp. Keeping pressing will increase the temp with 1°C per 0.5s.

⑦ HORIZ SWING: Activate or turn off wind horizontal swing function. (Only available when remote controller is used with corresponding unit.)

⑧ FAN SPEED:

Fan speed will be selected in following sequence once pressing this button: (Under the DRY and AUTO mode (except for the auto heat recycling mode), the fan speed will be fixed and can not be adjusted. Under the auto heat recycling mode, the fan speed will be automatically and can be adjusted.)



⑨ VERT SWING: Activate or turn off wind vertical swing function. Under the power off state, this button will not work. (Only available when remote controller is used with corresponding unit.)

⑩ STRONG:

Press this button, set the air conditioner to operate as strong mode, and the frequency will be raised, press again will cancel this mode. (Only available when remote controller is used with corresponding unit.)

⑪ DRY-AUXILIARY HEAT | FOLLOW ME:

Press the left of the button when it is operating the dry cleaning function, will close the dry cleaning function; press the right of the button when it is operating follow me function, will close the follow me function. (Only available when remote controller is used with corresponding unit.)

⑫ DISPLAY:

When the air conditioner is on the ON state, press this button, can close (open) the modules display, press again will open (close) the display. (Only available when remote controller is used with corresponding unit.)

8.2.3. Names of indicators and their functions




Fig.4-1

- ① Transmitting display: The icon will flash once when the signal is sent by remote controller.
- ② ON/OFF: Icon is displayed when the remote controller is turned on, or vice versa.
- ③ Running mode: Press MODE to display current running mode. AUTO, COOL, DRY, HEAT and FAN can be selected.
- ④ Timing ON/OFF: When adjusting timing ON state or only the timing ON function has been set, the "Timing ON" will be displayed; when adjusting timing OFF state or only the timing OFF function has been set, the "Timing OFF" will be displayed.
- ⑤ Lock: Press MODE and TIMER button for 5s simultaneously, lock icon will be displayed; Press buttons again, the icon disappears.
- ⑥ Temperature: Display the set temperature. Adjust temperature via " \triangle ", " ∇ ". No display in this area if the unit is on FAN mode.
- ⑦ Follow Me: Under the cool, heat, auto mode operation state, press the right of "DRY E•A•H | FOLLOW ME" button, the follow me icon will be displayed, and press again the icon will be disappeared.
- ⑧ Fan speed: Press FAN SPEED to display the current wind speed. AUTO, LOW, MED and HIGH can be selected. The default state is high fan speed for the unit without medium fan speed.



CAUTION

All the above icons are listed for instruction, and the relative items will be displayed when operation. And all the icons will be displayed when the remote controller is electrified for the first time or reset.

8.2.4. Operation instructions

8.2.4.1. Install and replace batteries

1. Install 2 pieces of 7# alkaline batteries.
2. Slide the cover to install batteries and make sure to place them in right pole.

8.2.4.2. Auto operation (Normal)

AUTO operation




Fig.5-1

1. Press MODE to select AUTO.
2. Adjust temp via \triangle and ∇ . Generally the range is 17°C~30°C.
3. Press ON/OFF and running indicator light on indoor unit is lightened. Air conditioner will work on AUTO mode and fan speed is AUTO, the display screen on remote controller will display "AUTO", then the fan speed is adjustable. And press ON/OFF again, the air conditioner will be stopped.

8.2.4.3. Dry / Fan / Cool / Heat operation

DRY/FAN/COOL/HEAT OPERATION




Fig.5-2

1. Press MODE to select COOL, DRY, HEAT or FAN.
2. Adjust temp via \triangle and ∇ . Generally the range is 17°C~30°C.
3. Press FAN SPEED to select AUTO, LOW, MED or HIGH.
4. Press ON/OFF and running indicator light on indoor unit is lightened. Air conditioner will work on the set mode. Stop operation via ON/OFF.



CAUTION

"FAN" operation can not set the temperature, when select this operation only can do 1,3,4 steps.
"DRY" operation can not set the fan speed, when select this operation only can do 1,2,4 steps.

8.2.4.4. Other function operation

Dry function

Function instruction

This air conditioner has dry function, close the unit under the cool and dry mode, the air conditioner will operate the dry function automatically, then the icon will be lightened. For cool-only model, the air conditioner will Low operate with fan mode for 10 mins and then close the unit automatically.




Fig.5-3

Stop operation


If you want to stop the dry function, can press the left of "DRY E•A•H | FOLLOW ME" under the function is operating, then can stop the function, and the icon will be off.

Follow me function

● Function instruction

This air conditioner has follow me function, when this function is operated, the remote controller will detect the temperature near the remote controller and compare with the temperature you set automatically, and control the operation of the air conditioner according to the contrastive result, and make the temperature near the remote controller reaches the setting temperature. This function is valid only under COOL, HEAT, AUTO mode and the unit has follow me function.

Fig. 5-4




- The remote controller can not be placed near the heat source or low temperature source, otherwise will affect its temperature gathering precision and then affect the follow me function.

Strong operation function

● Function instruction

When operating cooling, press the "TURBO" button and operate the strong cooling operation, at the same time raise the frequency, press again will close the strong operation.

Fig. 5-5



- This function is invalid under operating sleep function.

Energy-saving function

● Function instruction

When operating COOL/AUTO, press the "ECO" button, and operate power save function; press again will cancel the function.

- Under the DRY/FAN mode, this function is invalid.
- Under power save state, press "MODE", "ON/OFF" or "FAN" button will cancel this function.

Display function

● Function instruction

For avoiding the display light of the indoor unit will affect customer's rest, this unit has special display function. When the air conditioner is operated, press the "DISPLAY" button, then can close(open) the module display, press again can open (close) the display.

26°C green function

● Function instruction

Press "26°C" on the remote controller can operate the cooling operating mode with the setting temperature of 26°C.



Fig. 5-6

Lock function

● Function instruction

Press the "MODE" and "TIMER" button at the same time and last over 5s, then can operate locking the remote controller. In locked state, all the buttons are ineffective. Press the "MODE" and "TIMER" button again at the same time and last over 2s, then can close the locking.


Auto heat recycling mode function

● Function instruction

ΔT : Temperature difference, means the different temperature between the indoor temperature (T_f) detected by the remote controller and the remote controller setting temperature (T_s). (the default difference is 3°C, the difference range is 1~4°C)

 ΔT instruction

press \triangle and ∇ buttons for 5S simultaneously, then enter ΔT setting state.

 ΔT setting state

press \triangle or ∇ button adjust ΔT you want



press ON/OFF button confirm and exit the setting

SW1 definition

SW1	ON	1	2	Auto heat recycling Mode
SW1	ON	1	2	Auto Mode (Normal)

Example:

ΔT is 1°C, T_s is 25°C.

when $T_f - T_s \geq +\Delta T$, it will operate COOL mode, the fan speed will be operated according to the setting fan speed.

when $T_f - T_s \leq -\Delta T$, it will operate HEAT mode, the fan speed will be operated according to the setting fan speed.

Note:

This function operations only available when the indoor unit is in the heat recycling three-pipe system.

When the remote controller selects the auto heat recycling-mode, the remote controller position must be placed at the signal receiving range of the air conditioner.

When the remote controller detects changes of the mode (cool to heat, or heat to cool), it will send the changes to air conditioner. One beep of air conditioner changed mode signals is giving out.

**CAUTION**

5.4 Other functions operations only available when the indoor unit has corresponding functions.


8.2.4.5. Timer operation**Setting timing ON****Timing Setting**

Fig. 5-7

1. Under the remote controller is OFF, press the "TIMER" button, then the remote controller will display the timing ON icon and number display area will show up last timing ON time, and will display icon "h". The remote controller enters to the timing ON adjusting state.
2. (Continue) Press "TIMER" button, then can adjust the timing ON time to what you want.
3. After adjustment, the remote controller transmit the timing ON signal, and after 5s the icon "h" will be disappeared, and the number display area will back to display temperature, then finish the timing ON setting.




Fig. 5-8

1. Under the remote controller is ON, press the "TIMER" button, then the remote controller will display the timing OFF icon and number display area will show up last timing OFF time, and will display icon "h". The remote controller enters to the timing OFF adjusting state.
2. (Continue) Press "TIMER" button, then can adjust the timing OFF time to what you want.
3. After adjustment, the remote controller transmit the timing OFF signal, and after 5s the icon "h" will be disappeared, and the number display area will back to display temperature, then finish the timing OFF setting.

- ◎ Check the preset time of timing: press the corresponding timing button once, then will display the timing time.
- ◎ Change the timing ON or OFF time: press the corresponding timing button, then reset timing ON or OFF time.
- ◎ Cancel the timing: adjust the timing ON or OFF time to be 0.
- Timing the time to be relative time, that relate to the time which later than the standard time of operating the remote controller.
- Under the remote controller is ON, only can set timing OFF; under the remote controller is OFF, only can set timing ON.

6. Precautions

- Curtain, door or the like objects will prevent the remote signal from being received by air conditioner.
- Do not get the interior of remote controller wet. It is forbidden to expose it to direct sunlight or locate it in the place with high temp.
- Malfunction may occur if infrared signal receiver on air conditioner is exposed to sunlight. Please shelter the signal receiver from sunlight with curtain.
- Please remove the nearby electronic device for they may affect the performance of remote controller.
- Do not put the used or different batteries into the remote controller, otherwise remote controller will fail to send signal.
- Please remove the batteries before long period unused, otherwise the remote controller may be damaged.
- If pressing the button reset the remote controller, which indicates low battery, please replace the batteries.
- If no receiving sound is heard from indoor unit or on remote controller does not flash, please replace the batteries.
- Effective transmitting distance of remote controller is 8m, please aim the signal sending part to the receiver on air conditioner.

8.3. Wired remote controller KJR-29B

- This manual gives detailed description of the precautions that should be brought to your attention during operation.
- In order to ensure correct service of the wired remote controller please read this manual carefully before using the unit.
- For convenience of future reference, keep this manual after reading it.

8.3.1. Model and specification

• Main parameters

Table 2-1

Input voltage	DC +5V
Ambient temperature	-5~43℃
Ambient humidity	RH40%~RH90%

• Functions

Main functions of this wired remote controller as follows:

1. Connect with indoor unit via the four ports of A, B, C, D.
2. Set operation mode via buttons.
3. Provided with LCD display function.
4. Provided with timing function.

8.3.2. Wired remote controller outlook



8.3.3. Operation instructions

• Remote signal receiving function

The wired remote controller can be a remote signal receiving device, you can use the wireless remote controller to control the air-conditioner through the the wired remote controller when the system have been powerdon.



CAUTION

The wired remote controller will not receive the swing controlling instruction.

For the indoor unit with swinging function, you can directly use the wireless remote controller to control swinging through the display panel of the indoor unit, or use the swing button on the wired remote controller to control the indoor unit for swinging.

• On and Off the air-conditioner

Press the On/Off button to control the indoor unit on and off status.

When the unit is turned off, press the ON/OFF button, the unit will be turned on and the operating icon lights up.

When the unit is turned on, press the ON/OFF button, the unit will be turned off and the operation icon lights off.

• Set the operating mode

Press the mode button to set the operating mode, after each button press the operation mode will circle as follow:

AUTO→COOL→DRY→HEAT→FAN→AUTO

When the controller has been set to cool-only, then there is no HEAT mode.

• Fan speed setting

Under COOL, HEAT and FAN modes, press the fan speed button can adjust the fan speed setting.

After each fan speed button press will circle as follow:

AUTO→LOW→MID→HIGH→AUTO.

Under AUTO and DRY modes the fan speed is not adjustable and the default fan speed is auto.

• Temperature setting

Under AUTO, COOL, DRY, HEAT modes, press the temperature setting buttons and to set the temperature, the adjusting range is 17 °C ~ 30 °C

The setting temperature cannot be adjusted under FAN mode.

• Timer on and Timer off setting

Press the timer/clock setting button, then enter into the timer on setting status, and the screen will display and 0-0h.

Press and buttons to adjust the timer. when the timer setting is less than 10 hours, each press or will increase or decrease 0.5 hour. When the timer setting is more than 10 hours, each press or will increase or decrease 1 hour or decrease 1 hour, the maximum timer setting is 24 hours.

After finish adjusting the timer on setting, press the button or wait for 5 seconds to confirm and exit the timer on setting.

Under the timer on setting status, press the timer/clock setting button, then enter into the timer off setting status, and the screen will display and 0-0h.

The setting method of timer off is the same as the timer on.

Under timer setting state, set the timer on and timer off to be 0.0h can cancel timer on and timer off.



CAUTION

If the wired remote controller has been set timer on/off press the ON/OFF to turn on/ turn off the unit then the timer will be canceled simultaneously.

• Clock setting

Long press the timer/clock setting button for 3 seconds, then enter into the clock setting status.

The hour position of the clock will flash, and can press and to adjust the hour value.

After finishing the hour setting, press left button or right button to switch to minute position setting, then the minute position will flash, press and to adjust the minute value.

After finish the clock setting, press the button or wait for 5 seconds to confirm and exit the setting state.

• Quiet operation

Under COOL, HEAT, FAN modes, press the button to set into the quiet operation, it is used to reduce the running noise through setting the fan speed to low.

Under AUTO, DRY mode, the fan speed is auto and the button doesn't work.


• Lock the wired remote controller


Press the temperature adjusting buttons and simultaneously, the wired remote controller enters into locking state, and the lock icon will be lighted up.

Under the locking state, the wired remote controller will not respond to the buttons pressing and the control instruction from the wireless remote controller.

Simultaneously press the and temperature adjusting buttons and again can cancel the locking state.

• Air filter cleaning reminding function

The wired remote controller records the total running time of the indoor unit, when the accumulated running  time reaches the pre-setted value, the air filter of the indoor unit need to be cleaned.



Long press  for 3 seconds, and reset the reminding icon and the wired remote controller will re-accumulate the total running time of the indoor unit.




CAUTION


The default setting value of the reminding function is 2500 hours, and it can change to be 1250 hours, 5000 hours or 10000 hours. The setting methods please refer to the installation manual.

• Swing Function

If the indoor unit supports swing function, press the right button  to adjust the air outlet direction of the indoor unit. Long press this button for 3 seconds can turn on or turn off the auto swing function, the auto swing function, the swing icon  will be lighted up when the auto swing function is turned on.

• Follow Me function

When the system is running and the operating mode is AUTO, COOL or HEAT, press the  button will activate the Follow Me function, press the button again to deactivate the function. Operating mode changeover will deactivate the function as well.

when the Follow Me function is activated, the icon  will be light up, the wired controller will display room temperature read from the local sensor, and transmit the temperature value to the indoor unit every 3 minutes.



MUNDO  CLIMA[®]



www.mundoclima.com

ASK FOR MORE INFORMATION

Phone: (+34) 93 446 27 80

eMail: info@mundoclima.com

TECHNICAL ASSISTANCE

Phone: (+34) 93 652 53 57